



User Manual

Commercial Energy Storage
Three Phase High Voltage
Hybrid Inverter



Applicable Models:

S6-EH3P60K10-LV-YD-H-US

S6-EH3P75K10-LV-YD-H-US

S6-EH3P100K10-NV-YD-H-US

S6-EH3P125K10-NV-YD-H-US

S6-EH3P150K10-NV-YD-H-US

Important Notes

- Product specifications are subject to change without notice. Every attempt has been made to make this document complete, accurate and up-to-date. Individuals reviewing this document and installers or service personnel are cautioned, however, that Solis reserves the right to make changes without notice and shall not be responsible for any damages, including indirect, incidental or consequential damages caused by reliance on the material presented including, but not limited to, omissions, typographical errors, arithmetical errors or listing errors in the material provided in this document.
- Solis accepts no liability for customers' failure to comply with the instructions for correct installation and will not be held responsible for upstream or downstream systems Solis equipment has supplied.
- The customer is fully liable for any modifications made to the system; therefore, any hardware or software modification, manipulation, or alteration not expressly approved by the manufacturer shall result in the immediate cancellation of the warranty.
- Given the countless possible system configurations and installation environments, it is essential to verify adherence to the following:
 - There is sufficient space suitable for housing the equipment.
 - Airborne noise produced depending on the environment.
 - Potential flammability hazards.
- Solis will not be held liable for defects or malfunctions arising from:
 - Improper use of the equipment.
 - Deterioration resulting from transportation or particular environmental conditions.
 - Performing maintenance incorrectly or not at all.
 - Tampering or unsafe repairs.
 - Use or installation by unqualified persons.
- This product contains lethal voltages and should be installed by qualified electrical or service personnel having experience with lethal voltages.

Table of Contents

1 Introduction

2 Safety

3 Overview

4 Operating Modes

5 Installation

6 Commissioning

7 Troubleshooting

8 Datasheet

9 Appendix

Table of Contents

1. Introduction.....	01
1.1 Inverter Description.....	01
1.2 Components Included with the Inverter	05
1.3 Tools Required for Inverter Installation	05
1.4 Max. Conductor Sizes and Torque Specifications	07
1.5 External breaker and for single unit	07
1.6 Inverter Storage	08
2. Safety & Warning.....	09
2.1 Safety	09
2.2 General Safety Instructions	09
2.3 Notice for Use.....	11
2.4 Notice for Disposal	11
2.5 Protection Circuitry & Controls.....	11
3. Overview.....	12
3.1 LCD Display Screen & Indicator Lights.....	12
3.2 Inverter Wire Box & Connection Points.....	13
4. Operating Modes.....	14
4.1 PV-Only.....	14
4.2 Energy Storage.....	15
4.3 DC Coupling & AC Coupling.....	18
4.4 Backup Power Inverter Paralleling.....	20
4.5 Wiring Diagrams.....	25
5. Installation.....	26
5.1 Selecting a Location to Install the Inverter.....	26
5.2 Post mounting.....	27
5.3 Inverter Dimensions & Weight.....	29
5.4 Mounting the Inverter.....	30
5.5 Equipment Grounding.....	33
5.6 PV Cable Installation.....	34
5.7 Rapid Shutdown & Emergency Power Off.....	37
5.8 Battery Installation.....	41
5.9 AC Wiring.....	43
5.10 Smart Port: Generator, AC-Coupling, & Load Shed.....	48
5.11 Inverter Communication.....	49

Table of Contents

- 6. Commissioning.....60
 - 6.1 Pre-Commissioning Steps.....60
 - 6.2 Solis Loggers.....60
 - 6.3 SolisCloud.....61
 - 6.4 Power ON & OFF Procedures.....62
 - 6.5 HMI Commissioning Process.....63
 - 6.6 Mobile Application Commissioning.....72
- 7. Feature Introduction.....90
 - 7.1 Storage mode description.....90
 - 7.2 Time Of Use.....96
 - 7.3 AC coupling system.....97
 - 7.4 Generator integrated system.....101
 - 7.5 Parallel system.....105
- 8. Troubleshooting.....109
 - 8.1 Inverter Maintenance.....109
 - 8.2 Inverter Alarm Codes.....110
 - 8.3 Service Ticket Information.....114
 - 8.4 Inverter Firmware.....115
- 9. Datasheet.....116
- 10. Appendix.....120
 - 10.1 Default Settings for IEEE1547-2018 (UL-240V-18 Standard).....120
 - 10.2 Default Settings for California Rule 21 (R21P3-24A Standard).....122
 - 10.3 Frequently Asked Questions.....124
 - 10.4 FCC Instructions Page.....125
 - 10.5 Data Collection & Storage.....126

1. Introduction

1.1 Inverter Description

This Solis hybrid inverter series is designed for commercial solar plus energy storage applications where the power grid is 480V, 240V, 220V or 208V three phase. The inverter is able to maximize self-consumption while also providing backup power whenever grid power is lost. It can also utilize peak-shaving and time charging modes. The inverter is able to connect directly to a generator as well. The Solis S6 series consists of the following inverter models: 100kW,125kW,150kW, 60kW-LV and 75kW-LV (LV = “Low Voltage” 240V, 220V or 208V)

S6-EH3P(100-150)K10-NV-YD-H-US



123456789

Model Description

Item	Description
1	The sixth generation
2	E:energy H:Hybrid; A hybrid power system that integrates PV, battery energy storage, and grid to provide stable, efficient and reliable power supply.
3	Three phase
4	Rated output power of hybrid
5	10 MPPTS
6	Grid voltage normal(277 V / 480 V)
7	LCD screen
8	Compatible with high-voltage batteries
9	American version inverter

* LV means LV grid(120 V / 208 V, 127 V / 220V, 139 V / 240 V)

1. Introduction



1. Introduction




Figure 1.3 Right Side View



Figure 1.4 Left Side View

1. Introduction




Figure 1.5 Back View






Figure 1.6 Top View

1. Introduction

1.2 Components Included with the Inverter

If any of these items are missing, please contact your local Solis distributor or the Solis service team.

 Inverter x1	 Back plate x1	 Hex Head Bolt Assembly M10*40 x4	 Flat Washer $\Phi 10$ (C Grade Flat Washer) x4	 Hex Nut M10 x4	 Phillips Cross Recess Hex Head Bolt Assembly M10*20 x8
 Expansion Bolt M10*70 x4	 Phillips recess hex head combination screw M8*20 x2	 RJ45 connector x10	 DC connector x20	 Battery Quick-Connect Terminal Unlock Tool x1	 Battery quick-connect terminal (Black) x2
 Battery quick-connect terminal (Orange) x2	 Handle x4	 CT x3 (For Latin America)	 CT cables x1	 Dual RJ45 Plug Shielded Cable Harness - 5000mm x1	 Eastron Meter x1
 S2-WL-ST Data logger x1	 PV Terminal Unlock Tool x1	 Lifting Buckle x2	 Rogowski Coil x3 (For United States and Canada)		



NOTE

The CT cable lengths are 5 meters (16.4 ft.) and they cannot be extended.
If the installation requires an extension, an external meter must be installed.

1.3 Tools Required for Inverter Installation

Please notice, the following tools need to be prepared by customers.

 1	 2	 3	 4	 5	 6
 7	 8	 9	 10	 11	 12
 13	 14	 15	 16-17		

1. Introduction

NO.	Tool category	Tool name	Spec & No.	Function
1	Lifting tool	lift belt	500kg * 2	For inverter lifting
2		Buckle hook	500kg * 2	For inverter lifting, used in conjunction with lift belt
3	Installation	Impact drill	FM10	For M10 expansion bolt
4	Wire-making tool	Wire Strippers	12AWG to 6AWG	Stripping PV cables
5		Wire Strippers	20AWG to 10AWG	Stripping communication cables
6		LUG Crimping Tool	4AWG to 2/0AWG	For AC cables / battery cables
7		Wire cutter	4AWG to 2/0AWG	For AC cables / battery cables
8		Ethernet crimper	/	Crimping Ethernet cable
9		Crimper	MC4	Crimping MC4 PV connector and communication cable
10	Wiring tool	Technician Screwdriver	Φ3mm	For communication cable wiring
11		Screwdriver	Torqx T20	For communication cable wiring
12		Multi-bit screwdriver	/	For communication cable wiring
13		Electric Screwdriver	/	For installing or removing) screws
14		Socket/Bolt Wrench Tool (*)	Socket Sizes: 8 mm – 18 mm External Bolt Sizes: M10	For AC cables and Lifting installation
15	Testing tool	Multimeter (AC/DC amps)	/	For measuring AC/DC amps
16	Double hole OT terminal	M10 OT terminal	M10 * 10	For backup & smart port & Grid wiring
17		M10 OT terminal	M10 * 5	For neutral and PE wiring

1. Introduction

1.4 Max. Conductor Sizes and Torque Specifications

Terminal type	Recommend copper cable diameter (Copper 90℃)	Maximum support cable diameter (Aluminum 90℃)	The size of the fixed bolts	Cable Lug (Two hole lugs) (CAT.NO.)	Torque
Battery terminal	2AWG(35mm ²)	2AWG(35mm ²)	/	/	/
Backup	4/0AWG(110mm ²)	250KCMIL(120mm ²)	M10	60248/60254	10-12N.m
Smart Port	4/0AWG(110mm ²)	250KCMIL(120mm ²)	M10	60248/60254	10-12N.m
Grid	300KCMIL(150mm ²)	500KCMIL(260mm ²)	M10	60260/60271	10-12N.m
Backup PE	1/0AWG(55mm ²)	2/0AWG(70mm ²)	M10	60230/60236	10-12N.m
Smart Port PE	1/0AWG(55mm ²)	2/0AWG(70mm ²)	M10	60230/60236	10-12N.m
Grid PE	3/0AWG(85mm ²)	300KCMIL(150mm ²)	M10	60242/60260	10-12N.m

1.5 External breaker and for single unit

Item	Backup Breaker		Smart Port Breaker		Grid Port Breaker		Recommended Fuse (Battery)	Recommended Breaker (Battery)
	60K/75K	(100-150)K	60K/75K	(100-150)K	60K/75K	(100-150)K		
Rated Voltage (Ue)	≥ 230Vac	≥ 480Vac	≥ 230Vac	≥ 480Vac	≥ 230Vac	≥ 480Vac	≥ 1000Vdc	≥ 1000Vdc
Rated Current (In)	≥ 250A	≥ 225A	≥ 225A	≥ 225A	≥ 315A	≥ 315A	≥ 150A	≥ 125A
Altitude	2500m	2500m	2500m	2500m	2500m	2500m	2500m	2500m



NOTE:

If the Backup port operates under 1.6 times overload condition, a circuit breaker with higher instantaneous-trip current rating must be selected to prevent nuisance tripping.



NOTE:

The rated current (In)*N(where N is the number of units in parallel)

1. Introduction

1.6 Inverter Storage

- If the inverter is not installed immediately, please abide by the storage instructions and environmental conditions listed below.
- Use the original box to repackage the inverter, seal with adhesive tape with the desiccant inside the box.
- Store the inverter in a clean and dry place, free of dust and dirt. The storage temperature must be between -22~158°F and humidity should be between 0 to 100%, non-condensing.
- Do not stack more than two (2) inverters high on a single pallet. Do not stack more than 2 pallets high.
- Keep the box(es) away from corrosive materials to avoid damage to the inverter enclosure.
- Inspect the packaging regularly. If packaging is damaged (wet, pest damages, etc.), repackage the inverter immediately.
- Store inverters on a flat, hard surface -- not inclined or upside down.
- Do not remove the desiccant packet that is included with the inverter. It is included to ensure that any residual moisture is absorbed quickly.
- Restarting after a long period of non-use requires the equipment be inspected and, in some cases, the removal of oxidation and dust that has settled inside the equipment will be required.
- Perform an annual visual inspection of the inverter box for signs of damage
- If the inverter has been removed from the box and then replaced, put desiccant packets in the inverter wire box to ensure the internal components stay dry
- Do not store the inverter outside or in a place that does not have environmental controls.



**DO NOT STACK
MORE THAN 2 HIGH**

2. Safety & Warning

2.1 Safety

The following types of safety instructions and general information appear in this document as described below:



DANGER

“Danger” indicates a hazardous situation which if not avoided, will result in death or serious injury.



WARNING

“Warning” indicates a hazardous situation which if not avoided, could result in death or serious injury.



CAUTION

“Caution” indicates a hazardous situation which if not avoided, could result in minor or moderate injury.



NOTE

“Note” provides tips that are valuable for the optimal operation of your product.



WARNING: Risk of fire

Despite careful construction, electrical devices can cause fires.

- Do not install the inverter in an area containing flammable materials or gases.
- Do not install the inverter in a potentially explosive atmosphere.

2.2 General Safety Instructions



WARNING

Only devices in compliance with SELV (EN 69050) may be connected to the RS485 and USB interfaces.



WARNING

Do not connect PV array positive (+) or negative (-) to ground, doing so could cause serious damage to the inverter.



WARNING

Electrical installations must be done in accordance with local and national electrical safety standards.



WARNING

Do not touch any internal parts until 5 minutes after disconnection from the utility grid, PV array, and battery.

2. Safety & Warning



WARNING

To reduce the risk of fire, over-current protective devices (OCPD) are required for all circuits connected to the inverter.

The DC OCPD shall be installed per local requirements. All photovoltaic source and output circuit conductors shall have isolators that comply with the NEC Article 690, Part II.

All Solis three phase inverters feature an integrated DC disconnect switch.



WARNING

Risk of electric shock, do not remove the cover. There are no serviceable parts inside, refer servicing to qualified and accredited service technicians.



CAUTION

The PV conductors are energized with high voltage DC when the PV modules are exposed to sunlight.



CAUTION

The surface temperature of the inverter can reach up to 75 °C (167°F). To avoid risk of burns, do not touch the surface of the inverter while it is operating. The inverter must be installed out of direct sunlight exposure.



NOTE

PV modules used with inverter must have an IEC 61730 Class A rating.



WARNING

Operations must be accomplished by a licensed electrician or a person authorized by Solis.



WARNING

Installer must wear personal protective equipment during the entire installation process in case of electrical hazards.



WARNING

The AC Backup Port of the inverter cannot be connected to the grid.



WARNING

Please refer to the product manual of the battery before installation and configuration to the inverter.



Systems using this product shall be designed and built in accordance with the NEC & local electrical codes & standards.

2. Safety & Warning

2.3 Notice for Use

The inverter has been constructed according to the applicable safety and technical guidelines. Use the inverter in installations that meet the following specifications only:


1. Permanent installation is required.
2. The electrical installation must be compliant with all local and national regulations & standards.
3. The inverter must be installed according to the instructions stated in this manual.
4. The inverter must be installed according to the inverter technical specifications.

2.4 Notice for Disposal

This product shall not be disposed of with household waste. It must be segregated and brought to an appropriate disposal facility to ensure proper recycling.

This it to be done in order to avoid negative impacts on the environment and human health. The inverter contains materials that should not end up in a landfill.

Local waste management rules shall be observed and respected.



2.5 Protection Circuitry and Controls

To meet relevant codes and standards, the Solis U.S. three phase inverter line is equipped with protective circuitry and controls. These include Arc Fault Circuit Interrupter (AFCI) & Anti-Islanding Protection.

Arc Fault Circuit Interrupter AFCI:

Edition 2011 of the National Electrical Code®, Section 690.11, requires that all PV plants attached to a building are fitted with a means of detecting and interrupting serial electric arcs in the PV wiring and array. An electric arc with a power of 300W or greater must be interrupted by the AFCI in the time specified by UL 1699B. After five arc fault detections in 24 hours, an AFCI-induced shutdown will be triggered. If this event occurs, the inverter must be manually reset. After clearing the source of the fault, the inverter can be powered back on and allowed to resume normal operation.

Anti-Islanding Protection:

Anti-Islanding is a condition where the inverter cease to produce power when the grid is not present. Circuitry, along with firmware, has been designed to determine if the grid is present by adjusting the output frequency of the inverter. In the case of a 60Hz resonant system where the inverter is partially isolated from the grid, the inverter programming can detect if there is a resonant condition or if the grid is actually present. It can also differentiate between inverters operating in parallel and the grid.




NOTE:

All Solis inverters come with AFCI and Anti-Islanding protections integrated and enabled by default. The settings cannot be disabled or modified.

3. Overview

3.1 LCD Display Screen and Indicator Lights




#	Name	Description
1	Power LED	This LED is always red when the inverter has adequate AC or DC voltage. This LED does not indicate any problems.
2	Operation LED	This LED is always green when the inverter is operating normally and producing AC power.
3	Alarm LED	This LED is will light up yellow any time the inverter has an alarm code.
4	PV Icon	Represents PV power being generated in DC kW.
5	Battery Icon	Represents the battery connected to the inverter charging and discharging in DC kW and state-of-charge (SOC)
6	Inverter Icon	Represents the Solis hybrid inverter in the system.
7	Load Icon	Represents the grid-side building load consumption & power being exported to or imported from the grid in AC kW.
8	Backup Icon	Represents backup load consumption on the backup-side of the system in AC kW.
9	Generator Icon	Represents generator power being produced in AC kW.
10	Meter/CT Icon	Represents the energy meter monitoring the consumption power & import/export power to/from the grid in AC kW.
11	Grid Icon	Represents the grid and power being imported from/exported to the utility (grid) in AC kW.



NOTE:
The screen will turn off after a few minutes to conserve energy. Press any button to wake the screen up. Press the Enter button to access the main menu.

3. Overview

3.2 Inverter Wire Box and Connection Points




Name	Description
1. PV Switch1	PV switch of the PV1- PV6
2. PV Switch2	PV switch of the PV7- PV14
3. PV Switch3	PV switch of the PV15- PV20
4. PV Module Input	Conduit of PV conductors should be connected here
5. COM1	Communication cables of terminal block should go through this port
6. COM2	Communication cables of terminal block should go through this port
7. RSD	Disables the internal rapid shutdown (RSD) transmitter, initiating rapid shutdown. Engaging this switch disables all AC output from the inverter. Does not turn off battery.
8. RESERVE	Reserved port
9. COM	For Solis data logger connection
10. BlueTooth	A antenna for Bluetooth signal.no need operation
11. Battery Connection	Conduit of Battery conductors should be connected here
12. Grid	AC conductors to the main service panel should be connected here
13. Smart Port	AC conductors to a generator, AC-coupled PV system, or sheddable load connect here
14. Backup	AC conductors to backup loads panel should be connected here
15. Grid PE	Common bus bar for the grid ground conductors to terminate
16. AC Neutral Bus Bar	Common bus bar for all AC ground conductors to terminate
17. AC Ground Bus Bar	Common bus bar for all AC ground conductors to terminate

4. Operating Modes

4.1 PV-Only


4.1.1 Grid-Tied PV String Inverter

This inverter can be as a PV-only grid-tied string inverter. Only the PV/backup/ grid ports would be utilized. The inverter does have a feature allowing it to provide backup power with only PV. However, under PV-only load conditions, we do not support overload. This feature is great for short-duration (1-2) hour outages during the day with load consumption kept low. Batteries can always be added in the future, keeping the initial installation cost low. Overload faults occurrences and recover times are as follows: First - 30 seconds, Second - 3 minutes, Third, Fourth, Fifth - 10 minutes, Sixth - hard reset is required, no automatic recovery.



4.1.2 Export Power Control

The inverter offers the ability to manage export power. During the system commissioning process, export power control can be enabled. An export power limitation can then be set to the desired kW value. The inverter will then regulate how much power gets sold back to the utility company.



Each Solis hybrid comes with an energy meter, which gets installed externally to the inverter. The energy meter uses three CTs for three-phase, which measure the power being consumed and imported by the building. The hybrid uses the data from this meter to determine whether or not it needs to curtail the PV power to meet the export power limitation. Export power control can be enabled with or without a battery being installed.

Zero-Net Export

The inverter can be set to not export any active power to the utility. This does not end up being zero export as there is some power that leaks back to the utility each time there is a change in load demand. However, the *net import/export* will be near zero kWh each day when programmed for zero export.

NOTE:



The exported power cannot be kept to exactly zero. Solis export power control function is based on the measurements taken by the provided CTs or an external energy meter. Due to the sampling interval limitation, when there are sudden changes in load consumption small amounts of power will be exported. For stricter zero export applications, it is recommended to install an external backflow trip device. Solis does not sell this device.

4. Operating Modes

4.2 Energy Storage

4.2.1 Overview of Energy Storage Modes

The S6 hybrid is capable of providing AC power to loads using PV and battery power in the event of a grid failure. This is known as **backup power**. The amount of backup power that each S6 hybrid model can provide is equal to the amount of on-grid power that it can provide. For example, an 150K model can provide up to 150kW of continuous backup power.




Figure 4.1 Backup power with Solis S6 hybrid

If the primary purpose of the energy storage system is to store as much of the PV power as possible so that it can be used later to offset the consumption of grid power, this is known as **energy arbitrage**. *Time-of-use*, *self-consumption*, and *peak-shaving* are all examples of **energy arbitrage**. Typically, the battery will cycle daily as it charges with PV during the day and then discharges in the evening to cover building load demand.




Figure 4.2 Energy arbitrage with Solis S6 hybrid

The S6 hybrid can also operate in an entirely remote system where there is no grid present at all. This is called **off-grid** mode. It is very similar to backup in that the inverter will supply AC power to loads with PV and battery power only. However, backup mode is only for grid-connected systems.



NOTE:

The inverter is able to provide off-grid/backup power with only PV and no battery. However, the load consumption must remain less than the available PV power or else an overload fault will occur and the system will shutdown for five minutes.

4. Operating Modes

4.2.2 Energy Arbitrage

The three-phase hybrid inverter has multiple operating modes which can be programmed so that the performance of the system is tailored to the specific needs of each individual system owner. The backup power function of the inverter can be enabled or disabled independently of the energy arbitrage modes:(1) Self-Use (2) Selling first (3) Off grid (4) Peak-Shaving (Professional Setting)

Self-Use Mode(Self-Consumption)

Self-Use is the default energy storage mode. PV power will always supply the building loads first. Any excess PV power gets stored in the battery. If the battery is fully charged, the remaining power can be exported if the system is configured to allow it. If not, the PV power will be curtailed.




Figure 4.3 Self-Use Mode logic diagram

Selling First Mode(Export Priority)

This mode can be thought of as export priority mode. The system will first supply the loads with PV power and then it will seek to export the excess PV power, up to the set limit. Once the limit is reached, the remaining power will be stored in the battery. If the battery is fully charged, the PV will at that point be curtailed. This mode is for those who receive an equal rate for power exported or who have a much higher ratio of PV power generated to power consumed.




Figure 4.4 Selling first Mode logic diagram

4. Operating Modes

Off-Grid Mode

There is a dedicated mode specifically for 100% off-grid systems which are not electrically connected to the grid at all. This mode should not to be confused with backup mode, which occurs only for grid-tied systems. The logic for Off-Grid mode is the same as Self-Use mode. However, there is no export power control since there is no grid and a generator is often used in place of the grid to supplement the PV and batteries. When PV meets the load and there is still excess energy, this portion of PV charges the battery. If the battery has not reached the generator's "Off SOC" setting, the generator will continue to charge it. Furthermore, the battery must be connected to the inverter when the generator function is in use.




Figure 4.5 Off-Grid Mode logic diagram



NOTE: To utilize off-grid mode, the inverter must not be connected to the grid at all. There cannot be any conductors landed in the grid terminals.

Peak-Shaving Mode

Peak-shaving mode is ideal for those who pay a variable rate for energy based on the amount of consumed power (kw). This mode limits the power imported from the grid. The inverter will only discharge the battery when the power imported from the grid exceeds a specified amount (kW).





Figure 4.6 Peak-Shaving Mode logic diagram

4. Operating Modes

4.3 DC Coupling vs AC Coupling

4.3.1 DC-Coupling


DC-coupling is the recommended configuration for this inverter. This is because DC-coupling allows the full potential of this inverter to be utilized, maximizing the efficiency of the PV-to-battery charging. In a DC-coupled system, the PV also gets connected to the inverter in addition to the battery. The inverter will charge the battery directly with DC power from the PV. Typically, DC-coupling is done when additional PV is being added or when the system is new and being installed with energy storage.



The next section explains how the S6 hybrid can be AC-coupled. The next several sections following it will all focus on DC-coupling methods..

4.3.2 AC-Coupling at Grid Port

The Solis S6 hybrid can be DC-coupled or AC-coupled to a building to add energy storage. In an AC-coupled system the energy storage is connected to the AC-side of the system. Typically, the battery and Solis hybrid pairing get connected in parallel with an existing PV system. The battery will charge with PV power from the existing PV system. When AC-coupling with the S6 hybrid, new PV can either be added or not be added to the S6 hybrid, it is up to the system designer. The hybrid would just need to be installed with a compatible high-voltage battery and then be connected to the load center in parallel with the existing PV system.



The ability to be AC-coupled makes the Solis S6 hybrid ideal for system retrofits. The hybrid can be installed in place of the old PV inverter but with energy storage added.

4. Operating Modes

4.3.3 AC-Coupling at the Smart Port

An existing PV system can be AC-coupled (ACPV) to the Smart Port for backup support during outages. ACPV output must be less than the Solis hybrid inverter's rated power. "ACPV" refers to any AC-coupled PV system, while "PV" refers to DC-side connections on the S6. The ACPV breaker must be relocated into the backup load center so it remains energized during outages. When grid-connected, monitor grid-side consumption: if combined Solis + ACPV power exceeds the inverter rating, an overload alarm may occur.

The ACPV system connected to the smart port of the system must be smaller than or the same size as the Solis hybrid inverter. Export power must be set so that the maximum export power is equal to the Solis inverter nameplate power rating.



150kW
Solis Hybrid

+



30kW
ACPV

Export Power Set to 150kW



Energy Meter



Do not connect an ACPV system to the smart port of the system that is larger than the nameplate power rating of the Solis inverters. If there are multiple Solis inverters, then the combined total power.



100kW
Solis Hybrid

+



110kW
ACPV



It is recommended to install an external contactor switch in series between the Smart Port and the ACPV when connecting the grid-tied inverter to the Smart Port of the inverter. The Smart Port relay cannot be turned off at zero current, which will affect the relay's lifespan.

Suggested Specifications:
Circuit breaker/contacter, three-phase four-wire, rated current above 250A, supporting internal DO control turn-off of the inverter). When it is necessary to stop the AC couple function, first control the external switch to be disconnected, and then cut off the smartload port relay at zero current."

```
graph TD
    subgraph ON_grid [ON grid]
        S1[Supply loads] --> D1{Load demand met?}
        D1 -- Yes --> E1[The grid-Tied operates at full power with a load]
        D1 -- No --> E2[Discharge the battery]
    end

    subgraph OFF_grid [OFF-grid]
        S2[Supply loads] --> D2{Load demand met?}
        D2 -- No --> E3[The grid-tied is operating at full power and the battery is discharging]
        D2 -- Yes --> E4[Charge the battery]
        E4 --> D3{Battery at 50%?}
        D3 -- No --> E5[Adjust the output frequency of the Hybrid]
        D3 -- Yes --> E5
        E5 --> D4{ACPV supports frequency/watt shifting?}
        D4 -- Yes --> E6[When the battery SOC reaches 85, the grid-connected unit's max frequency reaches the value set by the customer, and at this time we will disconnect the smart port]
        D4 -- No --> E7[ACPV turns off]
    end
```

Figure 4.9 AC-Coupling (ACPV) with Backup Operating Logic

19

4. Operating Modes

Frequency Shifting

There is no direct communication between the Solis S6 hybrid and the AC-coupled PV system. The inverter uses frequency-shifting to modulate the output of the ACPV system. The inverter uses the frequency-watt curve outlined in the IEEE 1547-2018 standard. When in backup mode, the S6 hybrid will begin to shift the AC frequency when it detects that the power supplied by all of the PV, including the ACPV, is greater than the power demanded (consumed). This change in frequency will be detected by the ACPV system. If the ACPV system also supports the IEEE 1547-2018 frequency-watt curve, then its output power will reduce according to that curve. If the ACPV system does not support frequency-watt, then it will shut off as the frequency shifts and then turn back on once the S6 hybrid corrects the frequency.



NOTE:

The maximum output power of the existing PV inverter must be less than the maximum output power of the Solis hybrid inverter. AC coupling can be done on either the grid side or the smart port side. However, if it is on the smart port side, then the max. output power of the existing PV inverter must be less than the maximum output power of the Solis hybrid inverter. No power limitation applies when AC coupling is connected to the grid-side.

4.4 Backup Power Inverter Paralleling

Up to six hybrid inverters can be installed together in parallel on the backup side of the system. The backup ports of each inverter would terminate in separate overcurrent protection devices within the backup load center.




Figure 4.10 Backup with paralleled Solis hybrids

It should first be determined what the maximum continuous current needs to be in order to meet the energy demand of the home. Up to six S6 hybrid inverters can be installed in parallel with PV and batteries to provide continuous backup power. For example, three 150kW hybrids in parallel can provide up to 541.2A (180.4A x 3) of power to the loads in backup mode.

For a system with backup, the average daily power consumed should be less than or equal to the average daily PV power produced on any given day of the year. Otherwise, an overload condition may occur, causing the system to go down temporarily. The chart in Figure 4.16 shows how much continuous backup power can be produced depending on how many inverters are installed in parallel and what size they are.

4. Operating Modes

Surge Capacity & Passthrough Power

The **surge capacity** is how much power the inverter can generate for a small amount of time, usually one hundred milliseconds to ten seconds maximum. Each Solis model has different ratings for passthrough power and surge capacities. Installing multiple inverters in parallel increases the surge capacity and passthrough power. The chart in Figure 4.12 shows the surge capacities and passthrough power ratings for each model.

There will be times when the loads on the backup side consume more power than the inverter is able to provide with PV and battery power. The **passthrough power** is the amount of power that the can pass through the inverter from the grid to the loads when there is not enough PV and battery power available. The passtrough current of the S6-EH3P(100-150)K10-NV-YD-H-US is 250A.

Inverter Model	10s Surge Curent	200ms Surge Curent
S6-EH3P60K10-LV-YD-H-US	202.02A	230.88A
S6-EH3P75K10-LV-YD-H-US	252.56A	288.64A
S6-EH3P100K10-NV-YD-H-US	192.48A	240.6A
S6-EH3P125K10-NV-YD-H-US	240.64A	270.72A
S6-EH3P150K10-NV-YD-H-US	252.56A	288.64A


Figure 4.11 Surge Current Ratings based on Surge Duration

4. Operating Modes


4.4.1Paralleling Limitations and Restrictions

There are a few limitations to installing multiple inverters in parallel for backup power. Please note that these caveats do not apply when only paralleling on the grid-side. The restrictions shown below are only with respect to paralleling the backup-sides together. All inverters in the same system must be on the same firmware version. Please install one Solis data logger per inverter.


1. Paralleled inverters must be the same size (model number).




2. Do not parallel inverters that are different sizes. Again, this rule only applies to systems with backup power.




3. Paralleled inverters should have the same capacity (kWh), brand, and model of battery connected for maximum system efficiency. However, mixing and matching different batteries in the same system is acceptable.



4. Supports different capacities, but the capacity difference should be within 50% range. To ensure balanced charging and discharging in parallel, it is recommended that the battery capacity remain consistent.



5. Supports different brands, different models of the same brand, and different batteries connected to the same inverter.



NOTE:

CTs can be connected directly to the inverter without needing to install an energy meter. This only works for 2 inverters. When three or more inverters are being installed, the Easton energy meter must be installed. The hardware limit for CT mode is set at 600A.

4. Operating Modes



NOTE:

In an off grid parallel system, if the battery capacity is limited and some are connected to the battery while others are not, it is recommended that the battery be connected to the host

4.4.2 Power Control System (PCS)

The Solis S6 hybrid inverter is UL 3141 PCS certified. This means that the inverter is able to regulate the current and limit the loading on the bus bars and conductors. The PCS can limit the power flow as to not exceed any busbar rating limits. With PCS, the 120% rule for breaker sizing becomes irrelevant, you can go up to the busbar rating.



Solis Hybrid Inverter



Rogowski

Figure 4.12 Components of a Solis commercial PCS system



NOTE:

If you want to select Rogowski independently, the Rogowski need comply with UL2808 standards.

The certified meter and Rogowski models for this series are listed as follows:

Meter:SDM630MCT-OCS

Rogowski:ULNRC-60-85-2M 800A/class 0.5/600V/ -40°C ~ 80°C

ULNRC-100-85-2M 1500A/class 0.5/600V/ -40°C ~ 80°C

ULNRC-150-85-2M 3000A/class 0.5/600V/ -40°C ~ 80°C

ULNRC-200-85-2M 6000A/class 0.5/600V/ -40°C ~ 80°C

Solis Power Control System (PCS) Operating Modes

1. Import Only Mode: The system is permitted to charge the battery with grid power but is prohibited from discharge-exporting battery power to the grid.

S6-EH3P150K10-NV-YD-H-US: 180.4A

S6-EH3P125K10-NV-YD-H-US: 150.4A

S6-EH3P100K10-NV-YD-H-US: 120.3A

S6-EH3P75K10-LV-YD-H-US: 194.3A/180.4A

S6-EH3P60K10-LV-YD-H-US: 166.5A/144.3A

2. Export Only Mode: The system is permitted to discharge-export battery power to the grid but prohibits the use of grid power to charge the battery.

S6-EH3P150K10-NV-YD-H-US: 180.4A

S6-EH3P125K10-NV-YD-H-US: 150.4A

S6-EH3P100K10-NV-YD-H-US: 120.3A

S6-EH3P75K10-LV-YD-H-US: 194.3A/180.4A

S6-EH3P60K10-LV-YD-H-US: 166.5A/144.3A

4. Operating Modes

3.BBOC Mode:The system limits all power passing through the busbar

S6-EH3P150K10-NV-YD-H-US: 180.4A

S6-EH3P125K10-NV-YD-H-US: 150.4A

S6-EH3P100K10-NV-YD-H-US: 120.3A

S6-EH3P75K10-LV-YD-H-US: 194.3A/180.4A

S6-EH3P60K10-LV-YD-H-US: 166.5A/144.3A

4.PEL Mode:The system limits the maximum power exported to the grid.

S6-EH3P150K10-NV-YD-H-US: 180.4A

S6-EH3P125K10-NV-YD-H-US: 150.4A

S6-EH3P100K10-NV-YD-H-US: 120.3A

S6-EH3P75K10-LV-YD-H-US: 194.3A/180.4A

S6-EH3P60K10-LV-YD-H-US: 166.5A/144.3A

5.PIL Mode:The system restricts the maximum power imported from the grid.

S6-EH3P150K10-NV-YD-H-US: 250A

S6-EH3P125K10-NV-YD-H-US: 250A

S6-EH3P100K10-NV-YD-H-US: 250A

S6-EH3P75K10-LV-YD-H-US: 250A

S6-EH3P60K10-LV-YD-H-US: 250A



NOTE:

The PIL setting shall not be lower than the uncontrolled load determined by a load calculation using one of the methods required in NFPA-70 based on the PCS application.



Warning:

Risk of Loss of Power. If the setting of the PCS is lower than the sum of all loads or sources connected to, but not controlled by the PCS, overcurrent protective devices in the controlled conductors may open resulting in a loss of power to all circuits connected to the PCS.



NOTE:

This system is equipped with a power control system (PCS). All PCS controlled busbars or conductors shall be protected with suitably rated overcurrent devices appropriately sized for the busbar rating or conductor ampacity.



NOTE:

The maximum operating currents in controlled busbars or conductors are limited by the settings of the power control system (PCS) and may be lower than the sum of the currents of the connected controlled power sources.

The settings of the PCS controlled currents may be used for calculation of the design currents used in the relevant sections of NEC Article 690 and 705.



NOTE:

The maximum operating currents in controlled busbars or conductors are limited by the settings of the power control system and may be lower than the sum of the currents of the connected controlled power sources.




Warning:

Only qualified personnel shall be permitted to set or change the setting of the maximum operating current of the PCS. The maximum PCS operating current setting shall not exceed the busbar rating or conductor ampacity of any PCS controlled busbar or conductor.


4. Operating Modes

4.5 Wiring Diagrams

4.5.1 Backup System with One Solis Hybrid Inverter




4.5.2 Backup with Multiple Solis Hybrid Inverters



5. Installation

5.1 Select a Location to Install the Inverter

When selecting a location for the inverter, the following criteria should be considered:
Exposure to direct sunlight may cause output power derating due to overheating.
It is recommended to avoid installing the inverter in direct sunlight. The ideal location is one where the ambient temperature does not exceed 40°C (140°F)
It is also recommended to install the inverter somewhere the rain and snow will not land directly on it. The ideal installation location is on a north-facing wall under an eave.



WARNING: Risk of Fire



Despite careful installation, electrical equipment can cause fires.

- Do not install the inverter in an area that contains flammable materials, liquids, or gases.
- Do not install the inverter in a potentially explosive environment.
- The structure on which the inverter is being mounted must be fireproof.

5. Installation

5.1.4 Avoiding direct sunlight

Installation of the inverter in a location exposed to direct sunlight should be avoided.

Direct exposure to sunlight could cause:

- Power output limitation (with a resulting decreased energy production by the system).
- Premature wear of the electrical/electromechanical components.
- Premature wear of the mechanical components (gaskets) and user interface.

5.1.5 Air circulation

Do not install in small, closed rooms where air cannot freely circulate. To prevent overheating, always ensure that the air flow around the inverter is not blocked.

5.1.6 Flammable substances

Do not install near flammable substances. Maintain a minimum distance of ten feet (three meters) from such substances.

5.1.7 Living area

Do not install in a living area where the prolonged presence of people or animals is expected.

Depending on where the inverter is installed (for example: the type of surface around the inverter, the general properties of the room, etc.) and the quality of the electricity supply, the sound level from the inverter can be quite high.

5.2 Post mounting

You can also use the post mounting method to install the inverter,

1. The on-site post need to be fixed to the ground through components.
2. When using post mounting, the minimum ground clearance at the bottom of the inverter should be $> 1000\text{mm}$ (Considering cable bends).
3. Ensure that the surrounding environment meets the working environment requirements of the inverter.
4. For other installation-related matters, please consult Solis technicians.

Here it's the post mounting example schematic diagram.




Figure 5.2

5. Installation

When selecting a location for the inverter, consider the following:

WARNING: Risk of Shock



- Despite careful installation, electrical devices present a shock hazard.
- Install the equipment out of reach of children if children may be present.
 - Ensure that the equipment covers are always in place whenever the equipment is not being serviced.
 - Never service live equipment. Always turn the equipment off first. Use a multimeter to verify that conductor voltages are zero.

CAUTION: Hot Surface



- The temperature of the inverter heat sink can reach 176°F. Do not touch the heat sink while the inverter is operating.

The ambient temperature and relative humidity of the installation environment must meet the following requirements:

Maximum Temperature



140°F
60°C

Minimum Temperature



-13°F
-25°C

Max. Relative Humidity



100%
Non-Condensing

Maximum Altitude



9842 feet
3000 meters

Figure 5.3 Installation environment conditions

Load bearing structure requirements:



Made of nonflammable materials

Max. load bearing capacity ≥ 4 times of inverter weight. About the bearing wall.
Only supports wall-mounted installation with solid walls.




Figure 5.4 Load bearing structure

5.2.1 Clearances

- If multiple inverters are installed on site, a minimum clearance of 31.5 inches should be kept between each inverter and all other mounted equipment. The bottom of the inverter should be at least 39.4 inches above of the ground or floor.
- The LED status indicator lights located on the inverter's front panel should not be blocked
- Adequate ventilation must be present if the inverter is to be installed in a confined space.

5.2.2 Consult technical data

- Consult the technical specifications sections at the end of this manual for additional environmental condition requirements (temperature range, altitude, etc.)

5.2.3 Angle of installation

- This model of Solis inverter must be mounted vertically (90° degrees not greater or less than 90° degrees straight up).

5. Installation

5.3 Inverter Dimensions & Weight

The inverter weighs about 374.79 lbs (170 Kg) outside of the box.




Figure 5.5 Inverter Dimensions





Figure 5.6 Inverter Bracket Dimensions

5. Installation

5.4 Mounting the Inverter

- Mount the inverter on a wall or structure capable of bearing the weight of the machine
- The inverter must be mounted upright on a vertical structure with a tilt of 90°. A tilt greater or less than 90° may cause the inverter output power to derate.
- To prevent overheating, be sure that the inverter has adequate air flow around it. A minimum clearance of 23.62 inches (600mm) should be kept between inverter & other equipment. There must be 39.4 inches (1000mm) of clearance between the bottom of the inverter and the ground. Between the sides of the inverter and everything else, there must be a minimum of 7.9 inches of clearance.



- Visibility of the LCD screen should be considered. Ideally, the screen would be at eye-level.
- Adequate ventilation around the inverter must be provided.



NOTE:
Nothing should be stored directly on top, underneath, or against the inverter.

- When the inverter is mounted on the wall, it sticks out approximately one foot.
 - Keep this in mind when selecting the installation location for the inverter.
- The exact dimensions of the inverter and the mounting bracket are on the next page.

Once a suitable location has been found according to Figures 5.3 and 5.4, use figures 5.6 and 5.7 to mount the bracket to the wall. You may drill additional holes in the bracket if you need to you need to. The steps for mounting the inverter are listed below:

1. Place the bracket on the wall or inverter rack. The arrow in the middle of the bracket points up. With a pencil or marker, mark the mounting holes. Fasten the bracket to the wall. **If you are mounting the inverter to a wall, be sure the fasteners go into studs.**

5. Installation



NOTE:

The inverter must be mounted vertically at a 90° angle. Four fasteners must be used to ensure the bracket does not come off the wall. At least two must embed in a wall stud to bear the inverter weight.




Figure 5.8 Wall mount bracket

2. Lift up the inverter and align the back two hooks on the heat sync with the two tabs on the inverter mounting bracket. Lower the inverter hooks down onto the mounting bracket tabs and ensure the hooks have a solid bite before releasing the inverter. Then install the two set screws that are included with the inverter for stabilization.

Inverter handles

1. The inverter comes with two black handles that are removable and only required for safely lifting the inverter.
2. The position of handrails installation as the red mark in figure 5.9.
3. Whenever lifting the inverter or setting it down, do slowly and gently. This ensures that the internal components and the outer chassis do not take any damage.
4. Two people are required to remove the inverter as it is very heavy. Be sure to use the black handles.
5. Remove the handles by unscrewing them once the inverter has been mounted.




Figure 5.9 Inverter handle

5. Installation




Figure 5.10

There are two common types of lifting, as shown in the following figure. Users can adopt different types of lifting according to specific circumstances. The specific usage requirements are as follows.

Installation Tools (The following tools are to be prepared by the customer)

1. Socket/Bolt Wrench Tool: Outer bolt specifications: M8, M10;
2. Wrench Tool: Allen wrench and star-shaped Allen wrench set; Screw specifications: M6
3. Screwdriver Tool: Large and small cross and flat screwdrivers;
4. Torque Screwdriver: Torque screwdriver and a set of sockets (for wiring use, customers can choose according to their needs);
5. Electric drill and impact drill and accessories;

Wiring Tools (The following tools and terminals must be prepared by the customer)

1. PV terminal MC4 crimping tool, Ethernet cable crimping tool;
2. Communication terminal crimping tool;
3. OT terminal crimping tool: for wire sizes of 25~95 square millimeters, matching terminals are listed in the table below; wires and terminals need to be provided by the customer;
4. Accompanying wire stripping tools;
5. Accompanying heat shrink tubing and heat shrink tools;
6. Lifting tools (the following tools need to be provided by the customer)
 - M10 lifting ring *2,
 - 500Kg lifting strap *2,
 - Lifting hook *2 - a set,

As shown in the image below;




5. Installation

5.5 Equipment Grounding

An external ground connection is provided at the both sides of inverter.

Prepare OT terminals: M10. Use proper tooling to crimp the lug to the terminal.

Connect the OT terminal with ground cable to the right side of inverter. The torque is 10-12N.m.



M10 Screw removed
Torque: 10-12N.m

Figure 5.11 Connect the external grounding conductor

External grounding connection terminals are provided on both sides of the bottom bracket of the inverter. The grounding positions are as shown in the figure, located at the red circles. There are a total of 8 grounding positions on both sides.

Terminal type: OT terminal; Bolt type: M10. Use the appropriate tool to press the wire onto the terminal block.

Connect the OT terminal to both sides of the inverter, with a torque of 10-12 Nm.

To connect the grounding terminal of the bottom bracket, it is recommended to use copper wire. Solis conductors or stranded wires can be used. The specific wire size should refer to local standards and regulations.

5. Installation

5.6 PV Cable Installation



Before connecting inverter, please make sure the PV array open circuit voltage is within the limit of the inverter.




Before connection, please make sure the polarity of the output voltage of PV array matches the “DC+” and “DC-” symbols.



Please use approved DC cable for PV system.

1. Select a suitable DC cable and strip the wires out by $7\pm0.5\text{mm}$. Please refer to the table below for specific specifications.



Cable type	Cross section (mm ²)	
	Range	Recommended value
Industry generic PV cable	4.0~6.0 (12~10AWG)	4.0 (12AWG)

Figure 5.12

2. Take the DC terminal out of the accessory bag, turn the screw cap to disassemble it, and take out the waterproof rubber ring.




Figure 5.13

3. Pass the stripped DC cable through the nut and waterproof rubber ring.






Figure 5.14

5. Installation


4. Connect the wire part of the DC cable to the metal DC terminal and crimp it with a special DC terminal crimping tool.



5. Insert the crimped DC cable into the DC terminal firmly, then insert the waterproof rubber ring into the DC terminal and tighten the nut.



6. Measure PV voltage of DC input with multimeter, verify DC input cable polarity.



5. Installation

7. Connect the wired DC terminal to the inverter as shown in the figure, and a slight "click" is heard to prove the connection is correct.




Figure 5.18



CAUTION:

If DC inputs are accidentally reversely connected or inverter is faulty or not working properly, it is NOT allowed to turn off the DC switch. Otherwise it may cause DC arc and damage the inverter or even lead to a fire disaster. The correct actions are:

- *Use a clip-on ammeter to measure the DC string current.

- *If it is above 0.5A, please wait for the solar irradiance reduces until the current decreases to below 0.5A.

- *Only after the current is below 0.5A, you are allowed to turn off the DC switches and disconnect the PV strings.

- * In order to completely eliminate the possibility of failure, please disconnect the PV strings after turning off the DC switch to avoid secondary failures due to continuous PV energy on the next day.

Please note that any damages due to wrong operations are not covered in the device warranty.



NOTE

PV Simulator Operation & Safety Notice

1. Power-On Sequence: When using a PV simulator to test the inverter, you must turn on the inverter's PV DC switch first, and then turn on the PV simulator.

2. Power-Off Sequence: To shut down the system, always turn off the PV simulator first, and then turn off the inverter. Reversing this order may cause equipment failure or a fire hazard on site.

3. Critical Warning: Do not use a battery to simulate a real PV input for testing under any circumstances. This improper substitution can lead to equipment failure or a fire hazard.

5. Installation

5.7 Rapid Shutdown & Emergency Power Off

5.7.1 Integrated Rapid Shutdown Transmitter & Switch



Important Note

The inverter can be ordered with an internal rapid shutdown transmitter. This transmitter brand must match the receivers that are being installed with the PV modules. **Not abiding by this will void the inverter warranty.**

The internal transmitter generates a PLC signal when it receives AC power. This signal travels up the PV strings to the receivers that are connected to the PV modules. When the receivers get this signal, they turn on and allow the string voltage to ramp up. When the receivers lose this signal, they turn off. When the receivers are off, each PV module only puts out less than 1VDC. Pressing in this switch cuts power to the internal RSD transmitter. Engaging the switch will also cause the inverter to stop producing power. The inverter will enter a standby state in which it will not energize the backup ports or connect to the grid. It will not generate any power at all or interact with the battery until the switch is disengaged.

Rapid Shutdown & Emergency Power Off Initiation Process

1. Press the switch button in to turn off the internal transmitter. The PV string DC voltages will ramp down to safety-level within 30 seconds.
2. The inverter will also stop all AC power output to both grid and backup.
3. Twist the switch clockwise to turn the internal transmitter back on and bring the inverter back into a state of normal operation.



Note:

Rapid shutdown will only initiate if receivers have been installed in the PV array connecting to the PV modules directly.

Without the receivers the inverter can achieve emergency power off but it cannot achieve rapid shutdown..

Figure 5.19 Rapid Shutdown & Emergency Power Off Initiation Switch

Additional Details About Rapid Shutdown

1. With rapid shutdown receivers installed, the PV string voltages should be very low. Depending on the receiver type, you should be measure between 0.6 and 0.7Vdc per module. Example: x10 modules = 6V-7V for the whole string
2. If the PV string voltages are low, check that the AC breaker is turned on so that the inverter is getting AC voltage and that the rapid shutdown switch is popped out. Give the switch a twist clockwise to verify that is popped out.
3. The DC switch does not have to be turned on for the receivers to get the PLC signal from the internal transmitter. However, if an external DC switch is installed, ensure that it is turned on or else the receivers will not be able to get the PLC signal from the transmitter.

Please see the primary Compatibility sheet on the Solis US website for details on which internal transmitter options are available for this Solis hybrid inverter.

5. Installation

5.7.2 Photovoltaic Rapid Shutdown System (PVRSS) Certification

The Solis S6 hybrid is PVRSS-certified with several brands that manufacture rapid shutdown equipment. The certification includes the inverter, the PLC transmitter, and the receivers. The transmitter is located within the inverter, the receivers are installed with the PV modules. To avoid violating the PVRSS certification, the same brand of receivers must be installed as the internal transmitter. (Ex: Tigo transmitter with Tigo TS4-A-F and TS4-A-2F receivers). There can be nomixing of different brands without violating both the PVRSS certification and the rapid shutdown equipment warranty. For this reason, please be sure to check the Compatibility Sheet and only install equipment that is matched under the same brand. The only exception to this is Midnite Solar receivers, which can be used with either Tigo or APS transmitters.

Solis S6 Hybrid Inverter



Rapid Shutdown
PLC Transmitter



Rapid Shutdown
PLC Receiver



Figure 5.20 Components Listed in a Photovoltaic Rapid Shutdown System (PVRSS) Certification

Batteries and PV modules are not listed (specified) in the PVRSS certification. The transmitter can come integrated inside of the inverter, but it must be ordered with the correct internal transmitter. Alternatively, the transmitter can be installed externally in a separate enclosure.

5.7.3 External APS Solution for Single Inverter

The APsmart Rapid Shutdown System Transmitter-PLC-PLUS is part of a rapid shutdown solution when paired with APsmart RSD, a PV module rapid shutdown unit. While powered on, the Transmitter-PLC-PLUS sends a signal to the RSD units to keep their PV modules connected and supplying energy. RSD units automatically enter rapid shutdown mode when the Transmitter-PLC-PLUS is switched off and resume energy production when power is restored to the Transmitter-PLC-PLUS. This solution complies with NEC 690.12 specifications for 2017, 2020&2023 and supports the SunSpec signaling for rapid shutdown. The Transmitter-PLC-PLUS includes one or two cores and an optional power supply: 85-264VAC for residential, 180-550VAC for commercial.
(Ex: APS Transmitter-PLC, Transmitter-PLC-PCBA, Transmitter-PLC-1P, Transmitter-PLC-PLUS transmitter with APS RSD-S-PLC-A, RSD-S-PLC-B, RSD-D-20-1000 and RSD-D-20-1500 receivers).




Figure 5.21

5. Installation



NOTE:
The core has a maximum current rating of 400 A ($200\text{ A} \times 2$). This inverter is equipped with 10 MPPT channels, each carrying 42 A, resulting in a total current of 420 A which exceeds the core rating. Two transmitters are therefore required.


5.7.4 Cross-Talk

Cross-talk occurs when competing PLC signals sent from different transmitters reach the same RSD receivers. This causes the receivers to randomly cycle on and off at various times. Improper routing without cable trunking will lead to cross-talk interference. Cross-talk must be avoided to ensure proper inverter operation and to eliminate risk of damage to the system components. If multiple transmitters must be used, then it is important to keep the PV leads going from each inverter to the arrays separated by one foot minimum. Tigo transmitters can be physically wired together in a daisy-chain. Be sure to understand what kind of cross-talk protection the transmitter uses so that the system can be designed to eliminate any chance of cross-talk happening. If an external rapid shutdown transmitter is going to be used and the inverter has an integrated transmitter, then the integrated transmitter must be disabled to prevent cross-talk.

PV Conductor installation-multi-transmitter systems-required practices

When installing a system with 2 or more transmitters it is mandatory to use the following best installation practices of PLC circuits to ensure a trouble-free installation.

Run +/- string conductors from the same transmitter together in the same conduit.



Run +/- string conductors from the same string together through array and conduit.



Twist the +/- of the string.



If cable trays must be used, only lay conductors from the same transmitter in the cable tray and twist pairs.




Figure 5.22

The closer the conduit or cable tray the greater potential for crosstalk to occur.



Never separate the + and - of the same string.



Never separate the + and - of the same string.



Open cable trays provide no additional protection from crosstalk. Never place conductors from different transmitters in the same Cable tray.



Figure 5.23

5. Installation

5.7.5 External Rapid Shutdown & Emergency Power Off Switch

If the inverter is being installed where it is inaccessible to first responders, an external rapid shutdown switch must be installed somewhere accessible. Any 2-wire normally closed switch will work.

Steps for Installing an External RSD & EPO Initiation Switch

1. Install the external RSD switch and run two wires between it and the inverter
2. Connect one end of the two wires pins RSD
3. Connect the other end of the two wires to the external RSD switch
4. This is a normally-closed set of terminals. Be sure to use a normally closed switch.

Note: the RSD switch on the inverter wire box will still initiate rapid shutdown. Be sure the transmitter is on by giving the switch a clockwise twist when you are ready to energize the system.

**IMPORTANT:**

Installing module-level power electronics (MLPE) not listed on Compatibility List will void the inverter warranty and the MLPE warranties.

The external switch does not require compatibility matching, any normally closed switch will work with this inverter to initiate rapid shutdown.

**NOTE:**

Only remove the jumper when installing an external rapid shutdown switch.

In all other cases, do not remove the jumper, as it may cause the inverter to stop.

The external rapid shutdown initiation switch is sold separately. Please contact your local supplier for help with procurement. Solis recommends using an IMO switch.




Figure 5.24 External RSD Initiation Switch

5. Installation

5.8 Battery Installation



DANGER:
Before installing the battery cables, be sure that the battery is turned off.
Use a multimeter to verify that the battery voltage is 0Vdc before proceeding.
Consult the battery product manual for instructions on how to turn it off.



NOTE:
The condition for battery fully charging:
For this series of product, the compatible battery voltage should from 300-950V,
the charging and discharging current: 100A. Max. charge power is 130Kw and
discharge power is 150Kw.

5.8.1 Location of Battery Terminals

The inverter has two sets of inputs for two different batteries. The ports are labeled BAT1+ (battery 1 positive), BAT1- (battery 1 negative), BAT2+ (battery 2 positive), and BAT2- (battery 2 negative). It is crucial to not accidentally reverse polarity and connect a positive cable to a negative port or vice versa. These terminals can be a bit tricky to operate. The next page explains the correct process in detail.




Figure 5.25 Location of the battery terminals

Charging (S6-EH3P(60-150)K10-YD-H-US)			
NO.	Battery voltage(V)	Battery Current(A)	Battery Power(KW)
1	300	90	27
2	400	100	40
3	500	100	50
4	550	100	55
5	600	100	60
6	700	93	65
7	800	91	65
8	900	72	65
9	950	68	65

5. Installation

Discharge (S6-EH3P(60-150)K10-YD-H-US)			
NO.	Battery voltage(V)	Battery Current(A)	Battery Power(KW)
1	300	90	27
2	400	100	40
3	500	100	50
4	550	100	55
5	600	100	60
6	700	100	70
7	750	100	75
8	800	94	75
9	900	83	75
9	950	79	75

Battery Compatibility

This inverter only works with specific battery models. Please consult the Battery Compatibility Sheet on the Solis US website for which battery models this inverter will support. **Installing a battery that is not on the list will void the inverter warranty.** The inverter has two battery inputs and so can connect to two battery stacks at the most, unless the battery allows for paralleling stacks.



NOTE:
Before connecting the battery, please carefully read the product manual of the battery and perform the installation exactly as the battery manufacturer specifies in the manual



NOTE:
The suggested specification of the external battery circuit breaker for each battery is 125A. Ensure that the battery has an integrated breaker or install one.

5. Installation

Backup: This port remains energized with PV/ battery whenever the grid fails. Loads connected to the backup get power directly from the grid whenever there is not enough power available from PV/battery.

Grid: The inverter connects to the utility through this port. Excess PV power can be exported to the grid and the inverter can import power from the grid to charge the battery and support home loads.

Smart Port: This port is for connecting either a generator, an AC-coupled PV system, or a large load that can be shed during a grid outage if there is not enough power to support it (such as an EV charger)


AC Current Ratings for Sizing Over-Current Protection (OCPD)

To protect the inverter, we recommend installing a device for protection against over-current and leakage, based on the following current ratings noted in Figure 5.27

Inverter Model	Grid Max. Input Current	Max. Smart Port Input Current	Backup Max Surge Current (200 ms)
S6-EH3P60K10-LV-YD-H-US	250A	144.3A	288.6A
S6-EH3P75K10-LV-YD-H-US	250A	180.4A	288.64A
S6-EH3P100K10-NV-YD-H-US	250A	120.3A	240.6A
S6-EH3P125K10-NV-YD-H-US	250A	150.4A	288.64A
S6-EH3P150K10-NV-YD-H-US	250A	180.4A	288.64A

Figure 5.27 Current ratings AC inputs/outputs


5.9.2 How to Operate the AC terminals: Backup, Smart Port, and Grid Conductors



5. Installation

5.9.3 Aluminum Cable Requirements

When Aluminum cable is selected, use copper to aluminum adapter terminal to avoid direct contact between the copper bar and the aluminum cable. When using aluminum/copper wire rated lug, no additional adapters are required.



NOTE

Direct contact between the copper bar and the aluminum cable will cause electro mechanical corrosion and impair the reliability of the electrical connection



NOTE

Inverter OCPD must be selected in accordance with National Electrical Code® ANSI/NFPA 70 or the Canadian Electrical Code® CSA C22.1. Operating ambient temperature and humidity must be factored and considered when selecting OCPD for the inverter output.

Detailed wiring steps are as follows:

1. Disconnect the AC circuit breaker to ensure it won't accidentally turn on.
2. Strip a certain length from the end of the AC cable insulation sheath. The stripping length can be referred to in the following figure. Place the R-type terminals on both ends and make a crimp connection. The crimped part of the terminals must be insulated with heat shrink tubing or insulating tape.

Max inverter backfeed current to PV array: Current 0A , Continuous 0 ms.

Maximum output fault current on grid port:

Max.peak current: 520A, total duration:132ms.

Current (inrush)on grid port: Max.peak current 50A , Max duration 9.2ms.

5. Installation

3. When connecting to the grid port and the SMARTLOAD/GEN/INV ports, remove the three screws on the cover of the inverter junction box, and then remove the junction box cover.




Figure 5.29




Figure 5.30 CT Installation Location

5. Installation

Load Requirements for the Backup Side and Smart Port

These requirements apply to loads being connected to the backup side of the inverter or to the Smart Port when using it for load shedding.

1. Resistive and RCD loads

- a. For single-phase resistive loads, it should not exceed 100% of the single-phase power
- b. For RCD loads, it should not exceed 60% of the inverter's rated power.

2. Motor-based load

- a. When directly driving a motor load, it is necessary to pay attention to whether the starting impact power does not exceed the power and time limit of the inverter's overload curve.
- b. When using a frequency converter or soft-start type motor load, the power should not exceed 60% of the inverter's rated power.

3. RLC load

- a. The total load capacity shall not exceed the rated power of the inverter, the peak current at the moment of load switching (peak inrush current) shall not exceed twice the rated current of the inverter, and the minimum power factor shall not be less than 0.8.
- b. If a mixed load is adopted, apart from the RLC load, the motor load and the RCD load need to be proportionally reduced.

4. Isolation transformer

- a. If starting with a transformer, it is necessary to pay attention to the inrush current not exceeding 1.6 times the rated current and the inrush power not exceeding the overload curve limit requirements. Otherwise, a soft starter needs to be added to the transformer.

5. Installation

5.10 Smart Port: Generator, AC-Coupling, Load Shed

The inverter has a set of terminals called the “Smart Port”. Here you can connect either a generator, an AC-coupled PV system, or a large load such as an AC-EV charger that can be controlled while in backup mode.

5.10.1 Smart Port Location




Figure 5.31 Inverter smart ports

5.10.2 Smart Port Wiring

1. Bring the AC cables for the generator, load, or AC-coupled system into the inverter wire box.
2. Strip ½ inch of insulation from the ends of each conductor.
3. Insert a Phillips screwdriver into slot above the smart port terminal. Pull up on the screwdriver until you feel a click, the terminal is now open.
4. Insert the stripped end of each conductor into the correct terminal. Pull down on the screwdriver until you feel another click, the terminal is now closed (locked).
5. Connect a neutral conductor to the neutral bus bar and a ground conductor to the ground bus bar. Use the hex tool to tighten the terminal to between 10 and 12 N.m.
6. Give each cable a gentle tug test to ensure they are not loose.

The wiring diagrams in Figure 5.32 show the three different uses for the smart port.




Figure 5.32 Smart Port use case wiring diagrams



NOTE:

Can't connect to the generator when connected to the power grid, and cannot connect to the power grid when connected to the generator.

5. Installation

5.11 Inverter Communication

5.11.1 Communication Ports




Figure 5.33

Wiring steps for COM1-COM2:

Step 1. Loose the cable gland and remove the watertight caps inside the cable gland based on the number of the cables and keep the unused holes with watertight cap.

Step 2. Lead the cable into the holes in the cable gland.

(COM1: 4-hole fastening rings inside the cable . Hole Diameter: 5.3mm.

COM2: 10-hole fastening rings inside the cable . Hole Diameter: 1.5mm.)


Step 3. Connect the cable to the corresponding terminals inside the wiring box.

Step 4. Reassemble the cable gland and ensure there is no bending or stretching of the cables inside the wiring box.



NOTE:

Please separate the gap with hand and squeeze the cables into the holes from the side openings.



5. Installation

5.11.2 Communication Terminals




Figure 5.34

Terminal	Type	Description
CT	Push-In Terminal	For CT connection.
RSD		The positive and negative electrodes are short-circuited at the factory, the inverter will stop when disconnected. If customer has the requirement for RSD Function They need to use an external switch or external controller to control it.
EPO		Same logic as RSD function, Customized functions can be accepted from customers, allowing them to choose whether to shut down the system or merely stop PV output on this function.
GEN-DI1		Used for external ATS dry contact signal transmission.
GEN-DI2		Used for external power adaptor(DC12V/5V) dry contact signal transmission.
DI-1		Reserved for customized function.
GEN-DO1		Used for Generator start/stop signal.
GEN-DO2		Used for Generator start/stop signal.
AC C		Used for hybrid inverter control the external breaker to cutoff the PV inverter AC connection with hybrid inverter smart port.
SG-DO		Used for heat pump.
RS485		Used for 3rd party device control.
METER		Used to meter connection.

5. Installation




Figure 5.35

Terminal	Type	Description
BMS1	RJ45 Connector	For battery communication (CAN protocol).
BMS2		For battery communication (CAN protocol).
ETH		Ethernet port, support TCP/IP, used for other external communication, the standard Ethernet Port definition 1-TX+,2-TX-,3-RX+,6-RX-.
P-A		For parallel mode connection between inverters.
P-B		For parallel mode connection between inverters.
EMS		For external 3rd party EMS control.
DRM		For DRM function requirement in some regions.
DIP Switch	Switch	If a inverter is set as the first or last inverter in the parallel connection, you need to put all the DIP switch on this inverter to ON state , and the middle machine should be on OFF state.

5. Installation

5.11.3 BMS Terminal Connection

5.11.3.1 With Lithium Battery

CAN communication is supported between inverter and compatible battery models. Please lead the CAN cable through the COM1 or COM2 port of the inverter and connect to the BMS terminal with RJ45 connector.

Inverters of this series type support that customers using the batteries with different capacity and with different specification, but Solis recommend that using the batteries with same specification is better for the whole inverter system work excellently.




Figure 5.36



NOTE:
Before connecting CAN cable with the battery, please check whether the communication pin sequence of the inverter and the battery match; If it does not match, you need to cut off the RJ45 connector at one end of the CAN cable and adjust the pin sequence according to the pin definitions of both inverter and battery.

Pin definition of the inverter BMS Port is following EIA/TIA 568B.


CAN-H on Pin 4: Blue
CAN-L on Pin 5: Blue/White



NOTE:
Before connecting RS485 cable with the battery, please check whether the communication pin sequence of the inverter and the battery match; If it does not match, you need to cut off the RJ45 connector at one end of the RS485 cable and adjust the pin sequence according to the pin definitions of both inverter and battery.

Pin definition of the inverter BMS Port is following EIA/TIA 568B.


RS485A on Pin 6: Green
RS485B on Pin 3: Green/White



5. Installation

5.11.4 Battery Communication Wiring Table

The BMS1 and BMS2 ports are for communication between the battery and the inverter. The Figure below shows which pins on the inverter are for battery communication: CAN-H, CAN-L, RS485A, and RS485B. A standard ethernet patch cable can be used to connect the battery to the inverter. If the battery has pins instead of an RJ45 port, please cut one end off a standard ethernet patch cable and then connect it to the battery according to the pinout shown in Figure 5.37



IMPORTANT:

Solis cannot guarantee normal operation with any battery that is not on the approved battery list. Please only install batteries from this list.

Installing a battery that is not on the list will void the inverter warranty.

Battery Manual and Battery Firmware

Please be sure to read through the battery manual for proper installation steps. The battery manual should be provided with the battery or it can be downloaded from the battery manufacturers website directly. It is very important to update the firmware of the battery during the installation and commissioning of the system. **Failing to update both the inverter and battery firmware will lead to communication issues** and the alarm codes like CAN_Comm_Fail & No-Battery.



NOTE:



Some alarm codes are being relayed from the battery. These alarms are caused by an issue with the battery itself. The troubleshooting section of this manual explains how to diagnose and treat each alarm. If the alarm says the battery is having a malfunction, please contact the battery manufacturer.

5. Installation

5.11.5 Parallel Inverter Connection (Optional)

Up to 6 units of the inverter can be connected in parallel, if you have demand for 7-10 pcs in parallel mode, you should ask local solis technology support.
Please connect the paralleled inverters by using P-A and P-B terminals.
Standard CAT5 with shielding layers internet cable can be used.


- 1. ALL inverter MUST be connected to their own HV battery.
- 2. NOT support two or more inverters connect to the same one battery.



NOTE:
The primary is set with an ID of 1, secondary 1 should have an ID of 2, secondary 2 should have an ID of 3, and so on.
In a parallel system, if the battery number configuration is not one-to-one sufficient, only the secondary machine can be left unconnected, while the primary machine must be connected to the battery.
And the battery which one has the highest capacity we recommend you connect it to primary machine is better for system stability.



NOTE:
If the parallel machine is connected to the first and last consoles of the parallel connection, you need to put the DIP switch on the ARM board to "ON" position, and all the middle machines' DIP switch should be put to "OFF" position.



5. Installation

5.11.6 Paralleling Guidelines

In order to ensure normal operation and the safety of the equipment, the following rules must be followed when paralleling multiple inverters on the backup-side.

1. When connecting inverters in parallel, it is mandatory to match their sizes. For example, pair an 150KW inverter with another 150KW inverter. Do not parallel inverters of different sizes on the backup-side.
2. Before parallel connection, verify that both inverters are operating on the same firmware version. The inverters must never be on different versions of firmware.
3. Up to **six** hybrid inverters can be installed together in parallel on the backup side.
4. The energy meter and the data logger only need to be connected to the primary. But to update the firmware, each inverter needs to have its own data logger connected to it.
5. All inverters in the system must be connected to the same ground point to eliminate the possibility of a voltage potential existing between inverter grounds.
6. Each inverter must have its own PV strings connected to it, as per the DC input PV specifications of the inverter. It is ok to have some inverters with only battery and no PV.
7. The inverters support batteries with different energy capacity from different brands.
8. The inverter backup circuit breakers must be connected in a separate isolated load center that is not electrically connected to the grid.
9. The AC bypass switches for all inverters must all be in the same position always.
10. The parallel settings for each inverter must be configured prior to initiating operation.
11. Prior to initiating full system operation it is essential to verify that each inverter operates normally. Set each inverter one-by-one for single operation, ensure there are no alarms during operation, shut it down, and then go to the next inverter.



NOTE:

A failure of the main unit will cause the entire system to shut down, but a failure of the secondary unit will only cause the inverter to shut down, without affecting the operation of other inverters in the parallel system.

5. Installation

5.11.7 RS485 Port Connection (Optional)

If a 3rd party external device or controller needs to communicate with the inverter, the RS485 port can be used. Communication protocol is supported by Solis inverters. To acquire latest protocol document, please contact Solis local service team or Solis sales.




NOTE:

Pin definition of the RS485 Port is following EIA/TIA 568B.

RS485A on Pin 5: Blue/White

RS485B on Pin 4: Blue



Third-Party Monitoring with RS485 Modbus

If third-party monitoring is to be installed, connect the third-party gateway to the RS485 port of the inverter. Use pin 4 (blue) for RS485B and pin 5 (blue-white) for RS485A.

The Solis hybrid inverter Modbus map can be downloaded from the Solis website or requested from the Solis service and support team

5. Installation

5.11.8 Generator communication connection

The GEN-DO1(Pin11,Pin12), GEN-DO2(Pin13,Pin14) are DO ports. You can use this ports to output dry contact signal to generator to control the generator start or stop automatically.

The GEN-DI1 (Pin5, Pin6), GEN-DI2 (Pin7, Pin8) are DI ports, If you have installed generator with ATS device. You can use the this ports connect to ATS or Power Adaptor(12V/5V) to detect the power grid state, if grid tripped, the ATS OR Power Adaptor will send dry contact signal to hybrid inverter.




Figure 5.40

5.11.9 EMS port connection

This port supports the RS485_MODBUS communication protocol. It can be used as a communication port between the main inverter and third-party EMS. For the communication protocol documentation, please contact the local Solis service team or Solis sales to obtain the latest version.




NOTE:

Pin definition of the EMS Port is following
EIA/TIA 568B.

RS485A on Pin 5: Blue/White

RS485B on Pin 4: Blue



RS485A
RS485B

5. Installation

5.11.10 Meter/CT Connection



CAUTION:

Make sure the AC cable is totally isolated from AC power before connecting the meter or CT.




Figure 5.41 Meter wiring

5. Installation

5.11.11 Parallel Wiring




Figure 5.42 Parallel Wiring

6. Commissioning

6.1 Pre-Commissioning

1. Visually inspect each piece of equipment in the system closely.
2. Check all conduit and cable connection points to ensure they are tight.
3. Verify that all system components have adequate space for ventilation.
4. Follow each conductor from end to end. Confirm that they are all terminated in the proper places.
5. Ensure that all warning signs and labels are affixed on the system equipment.
6. Check that the inverter is secured to the wall and is not loose or wobbly.
7. Prepare a multimeter that can do both AC and DC amps.
8. Use the multimeter to measure the PV string voltages in free air. With RSD the voltages will be low.
9. Land the PV strings, turn on the grid-side breaker and the battery. Keep the inverter DC switch turned off. Measure the PV string voltages again. Verify that the polarities and voltages are correct.
Note: if the PV voltages are still low with the PV strings landed and the grid-side breaker turned on, check the rapid shutdown switch on the side of the inverter. Give it a clockwise twist to pop it out.
10. Check the AC voltages coming from the grid. Check the battery DC voltage and verify polarity.
11. Leave the inverter DC switch turned off for now. Only turn it on once you are ready to put the system into normal operation. Leave the battery on and the AC breaker connected to the grid-side on as well.
12. Download the battery app, register an account, and then be sure to update the battery firmware if there is a new version available. This step is very important and skipping it can lead to comms issues.

The next steps will be to install a Solis logger, download the SolisCloud application, register a new account on SolisCloud, and then configure the inverter settings using the SolisCloud app. After that is all done, the logger will need to be connected to the Wi-Fi and configured using SolisCloud
Note: Installing a Solis logger is optional. Third-party monitoring can be used instead.

6.2 Solis Loggers

6.2.1 Solis Monitoring with Solis Data Loggers

For remote monitoring and control of the inverter using the Solis monitoring portal, a Solis data logger must be installed. The logger gets plugged into the port on the side of the inverter shown in the figure below. First, remove the black plastic protective cap from the port by squeezing in both tabs on either side simultaneously while pulling down on the cap. Insert the logger into the port by pressing up evenly on both sides, **do not twist the logger**. The logger port is USB-A and only supports USB versions of Solis data loggers, not the 4-pin versions. The Solis logger can only report to SolisCloud. If a 3d party monitoring platform is to be used, a 3d party gateway must also be used.

6. Commissioning

6.2.2 Compatible Solis Loggers

This inverter comes with an S2-WL-ST, which has both a Wi-Fi and a local area network (LAN) option consisting of an RJ45 port for direct connection to a router.




S2-WL-ST

Data Logger Model	Communication Type
S2-WL-ST (USB)	Wi-Fi (2.4 GHz) Local Area Network (LAN)



S2-WL-ST Manual

Figure 6.1 Compatible Solis Data Loggers



6.3 SolisCloud

SolisCloud is the monitoring platform where inverters can be monitored remotely. You will need to download the SolisCloud app and then register a new account. Please scan the QR code to pull up the app in the App Store or search “SolisCloud” and then look for the icon shown in the middle of the QR code. There are two account types available: Installer and Owner

Installer: for technicians and anyone that is not the asset owner such as the homeowner where the system is being installed. Installer accounts are for fleet management and are able to remotely control registered plants remotely through SolisCloud.

Owner: for homeowners who typically only have a small number of sites and are only looking to monitor their system(s) and not have any control.

Once the account registration has been completed, log into the SolisCloud app. You will use the app to configure the Wi-Fi settings of the Solis logger and the inverter settings while on-site.





6. Commissioning

6.4 Power ON & OFF Procedures

6.4.1 Power ON Procedure

Step 1: With the DC switch off, energize the PV strings and then measure DC voltage of the PV strings to verify that the voltage and polarity are correct. Turn on the battery and check the battery voltage and polarity as well.



Step 2: Turn on the OCPD for the system and then measure the AC voltages line to line and line to neutral. The backup side of the system will be off until commissioning is complete. Turn the OCPD back off for now.

Step 3: Turn the DC switch on and then the OCPD (AC breaker) for the system. This inverter can be powered on by PV only, battery only and Grid only. When the inverter is powered on, the five indicators will be lighted at once.

6.4.2 Power OFF Procedure

Step 1: Turn off the AC breaker or AC disconnect switch to disable AC power to the inverter.

Step 2: Turn off the DC switch of the inverter. Do not turn the DC switch off first.

Step 3: Turn off the battery breaker.

Step 4: Use a multimeter to verify that the battery and AC voltages are 0V.



IMPORTANT:

Never turn the DC disconnect switch from on to off position while the inverter is operating. This switch is not a load-break disconnect switch. Not abiding by this will void the inverter warranty.

6. Commissioning

6.5 HMI Commissioning Process

6.5.1 HMI Quick Setting

If this is the first time the inverter has been commissioned, you will need to first go through the Quick Settings. Once this has been done, these settings can be changed later.

Inverter Time -> Meter Setting -> Grid Code -> Storage mode -> Battery Model

The screenshot shows the 'QUICK SETUP' screen with a timestamp of 2024/01/01 12:00:00. The screen is divided into two main sections. The left section contains 'Inverter time' settings (Year: 2024, Month: 01, Day: 01; Hour: 12, Minute: 00, Second: 00), 'CT/METER settings' (CT selected, Location: Grid, Direction: forward, CT ratio: 4000:1), and 'Grid settings' (Grid code: G95). The right section contains 'Storage mode' settings (Self-use and Allow export selected, Selling first selected, Off grid unselected) and 'Max export power' settings (Max export power: 200W, Export calibration: 20W, Grid Peak shaving: 2000W). A 'NEXT' button is located at the bottom right.

1. Inverter time:

Set inverter time and date, default follow the phone.

2. CT/Meter setting:

Select the CT or Meter: Solis provide Easton 3 phase meter, it is self-identifiable.

Set installation location: Grid side / Load side / Grid+PV inverter;

CT direction: When CT installed correctly, select “Forward”; when CT installed direction wrong, the sampling current of CT will be reversed when calculating the power, select “Reversal” to correct it.

Set CT ratio: default 120, if the user install their own CT, then need to set the CT ratio manually. If the system connected to Meter, then CT ratio need to be set on Meter.

3. Grid code:

Select grid code that meet the local regulations.

4. Storage mode:

ALL modes first priority is to use the available PV power to support loads. The different modes determine what the second priority, or use of the excess PV power, will be.

Self-use / Selling first / Off-grid are exclusive, the user could select only one mode.

5. Battery setting:

Select Battery connection method 1 Batt 1 DC / 1 Batt 2 DC / 2 Batt; the connection method please refer to 3.13 Lithium battery wiring.

Select battery brand (if the connected battery is not on the list, please select “General_LiBat_HV”).

Set Max charging/discharging current.

If there are two batteries and share the same settings, please tick the box of “Batt2 Settings follow Batt 1”.

6. Commissioning



Mode	Description
Self-use	PV power flow priority sequence: loads > battery > grid. In this mode, the system stores excess PV power into the battery after the loads are supplied. If “Allow export” turned on, when the battery is charged full, or there is no battery, the excess PV power will be exported(sold)back to the grid. If the system is set to not export any power, then the inverter will curtail the PV power (derate the inverter output power).
Selling first	PV power flow priority sequence: loads > grid > battery. In this mode, the system exports any excess PV power after the loads are supplied. If the export power quota has been met, then the remaining PV power will be stored in the battery. Notice: This mode should not be used if export power set to zero.
Off grid	PV power flow priority sequence: loads > battery. This mode only used when the system are not electrically connected to the grid at all. This mode is like Self-Use Mode, but the PV power will be curtailed if the PV power output is > battery power + load power


Table 1 Description of modes

Under each mode, user could set other functions based on their requirements.

Settings	Description
Max export power	Default: 1.1 times of rated power. Notice: if feed-in is not allowed, set Max export power to 0.
Export calibration	Range : -500w-500w, default 20w, settable. To compensate the deviation of CT/Meter in practical application.
Grid peak shaving	Default enable, default 2 times of rated power. Limit the power drawn from the grid to prevent from exceeding regulatory requirements or the power line capacity. It works only when the “battery reserve” turned on.

Table 2 Description of mode settings

6. Commissioning




6. Commissioning

6.5.2 Detailed HMI Setting

Step 1: Enter Home page

After quick setting, press “ENTER”, the screen displays the home page.



The screen will be automatically turn off after being idle for a few minutes to save power, click any operation button “ESC”/”UP”/”DOWN”/”ENTER”) to restart the screen, then press “Enter” into the main operation interface.

Step 2: Enter “SYSTEM SETTING” interface

Press“Down” button, then press “ENTER” into the “SYSTEM SETTING” interface.



6. Commissioning

Step 3: Set “Storage Mode”

Use “UP” or “DOWN” key to select the desired mode, then press “ENTER”.

The Mode description please refer to 5.4.1.

STORAGE MODE

2024/01/01 12:00:00

Storage mode

☐ Self-use

☒ Allow export

☒ Selling first

☐ Off grid

PV power

☒ Batt first

☐ Load first

☒ Batt reserved

80%

☒ Allow grid charging

Max export power

200W

Export power calibration

20W

☒ Grid Peak shaving

2000W

1/2

Settings	Description
Battery reserve	Range: 5~95%, default: 80%, settable. When battery SOC < set battery reserve SOC, battery will stop discharging.
Allow grid charging	Allow grid charging the battery when it enables. Notice: if “Allow Grid Charging” is turned on, the inverter will use grid power to charge the battery only under two circumstances: The battery drains to the Force Charge SOC. When PV power output can’t meet the set current value during the charge periods.
Max export power	Default: 1.1 times of rated power. Notice: if feed-in is not allowed, set Max export power to 0.
Export calibration	Range : -500w-500w, default 20w, settable. To compensate the deviation of CT/Meter in practical application.
Grid peak shaving	Default enable, default 2 times of rated power. Limit the power drawn from the grid to prevent from exceeding regulatory requirements or the power line capacity. It works only when the “battery reserve” turned on.

Table 3 Description of storage mode settings



NOTE:
The grid import limit value must be greater than the load that is to be supported.
This ensures that the load will operate normally.

6. Commissioning

Step 4: Set “Time of use” under each mode (Skip this step if no need)

Time of Use is for manual control of the battery charging/discharging. It is for customizing when the battery is allowed to charge and discharge power and at what rate, established by a current(amperage)setting.

- 1. Charge period: battery charges with set current value until the charging cut-off voltage (settable), checking the box to control whether enable this charging period.
- 2. Discharge period: battery discharges with set current value until the discharging cut-off voltage (settable), checking the box to control whether enable this discharging period.

STORAGE MODE

2024/01/01 12:00:00

Charge period

	Start	Stop	Current	SOC
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%

Discharge period

	Start	Stop	Current	SOC
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%
☒	01 : 00	05 : 00	100A	50%
☐	01 : 00	05 : 00	100A	50%

2/2



NOTE:
The set current value is the maximum current for charging/discharging the battery. However, the actual charging and discharging current may not reach this value due to the influence of other factors, such as the max. charging/discharging power limitation of the inverter, the battery BMS, etc.

6. Commissioning

Step 5: Set “Battery Setting”

BATTERY SETTING2024/01/01 12:00:00

Battery connection method

18Batt 1DC

18Batt 2DC

28Batt

Batt1 type

Lithium Battery

PYLON_LV

48.0V Lithium Battery (Without COMM)

51.2V Lithium Battery (Without COMM)

Lead-acid Battery

No Battery

Max charge current100A

Max discharge current100A

Over discharge80%

Recovery80%

Force charge80%

Max charge SOC80%

Battery saving

Batt2 Settings follow Batt1

Batt2 Setting

1/2

Settings	Description
Max charge current	Max charge current, settable.
Max discharge current	Max discharge current, settable.
Over discharge	Range: 5~40%, default 20%, when battery SOC < over discharge, it will stop discharging.
Recovery	Range: set Over discharge value +1% ~ set Over discharge value +20%; when battery SOC > Recovery SOC, it will start charging, reserve the return difference value to avoid the battery repeatedly cross jump between charging and discharging.
Force charge	Range: set Over discharge value +1% ~ set Over discharge value +20%; when battery SOC > Recovery SOC, it will start charging, reserve the return difference value to avoid the battery repeatedly cross jump between charging and discharging.
Max charge SOC	Charge cut-off SOC, battery stops charging when reach the Max. Charge SOC.

Table 4 Description of battery mode settings

NOTICE:
Force charge SOC < Over discharge SOC < Recovery SOC, otherwise the setting might be error.

69

6. Commissioning

Step 6: Set “Grid Port”

(Skip this step if grid code is already set in quick setting)

Select grid code that meet the local regulations.

Three level of Over-voltage / under-voltage / Over-frequency / under-frequency are default based on grid code, there is no need to set the parameters in manual.

GRID PORT

2024/01/01 12:00:00

Grid code

G95

>

☒ Grid Neutral Connection

HV1

255.5V

--

0.1s

HV1_T

HV2

260.0V

--

0.1s

HV2_T

HV3

265.0V

LV1

250.0V

--

0.1s

LV1_T

LV2

250.0V

--

0.1s

LV2_T

LV3

250.0V

HF1

50.0Hz

--

0.1s

HF1_T

HF2

51.0Hz

--

0.1s

HF2_T

HF3

52.0Hz

LF1

49.0Hz

--

0.1s

LF1_T

LF2

48.0Hz

--

0.1s

LV2_T

LF3

47.0Hz

1/2

Step 7: Set “Smart Port”

(Skip this step if the system is not connected to generators)

When it is connected to Generator, select “Gunset input”;

When it is connected to smart load like heat pump select “Smart load output”

When it is connected to Grid-tied inverter select “AC coupled”

SMART PORT

2024/01/01 12:00:00

☒ Gunset input(Note:Need to connect gunset signal)

Gunset rated power

3000W

☒ Gunset connected to grid

☐ Manual

☒ Enable

☒ Automatic

OFF

90%

ON

80%

☐ Smart load output

OFF

50%

ON

50%

☒ On grid always on

☒ Off grid always off

☐ AC couple input

Max freq

60.5Hz

1/1

Gunset

The user need to input the “Gunset rated power” by manual.

OFF: Generator stops charging SOC, settable, range:35~100%;

ON: Generator start charging SOC; settable, range:1~95%;

AC coupled:

OFF: Grid-tied inverter stops charging SOC, settable, range:35~100%;

ON: Grid-tied inverter start charging SOC; settable, range:1~95%;

6. Commissioning

Step 8: Set parallel system

Set primary and secondary machine,
Set primary ID as: 1
secondary machine ID as: 2
.secondary machine ID as: 3
..... and so on.

PARALLEL SYSTEM2024/01/01 12:00:00

☒ Parallel system

Master-slave setting

☒ Master

☐ Slave

ID1

1/1


6. Commissioning

6.6 Mobile Application Commissioning


6.6.1 Log in the APP via Bluetooth

Step 1: Connect with Bluetooth.

Turn on Bluetooth switch on your mobile phone and then open the Soliscloud APP. Click “More Tools”->”Local Operation”->”Connect with Bluetooth”




Step 2: Select the Bluetooth signal from the inverter. (Bluetooth Name: Inverter SN)



Step 3: Login account.

If you are the installer, please select the account type as Installer. If you are the plant owner, please select the account type as owner. Then set your own initial password for control verification. (The first log-in must be finished by installer in order to do the initial set up)



6. Commissioning


6.6.2 APP Quick Setting

If this is the first time the inverter has been commissioned, you will need to first go through the Quick Settings. Once this has been done, these settings can be changed later.

Inverter Time -> Meter Setting -> Grid Code -> Storage mode -> Battery Model

(1) Inverter time:



Set inverter time and date, tap the slider next to “Follow Phone Time”, then tap “Next step” at the bottom right corner.



6. Commissioning

(2) Battery:



- Select the number of battery banks 1-2
- Select the battery model: if the connected battery brand is not on the list, please select "General_LiBat_HV"
- Select battery connection method either a single battery and BMS connected to one input or two batteries and one BMS connected to both inputs.



6. Commissioning

(3) CT/Meter setting:

- Select CT or Meter;
- Set Meter type (the Eastron 3 phase meter is self-identifiable)
- Set Meter installation location: Grid side / Load side / Grid+PV inverter;
- Set CT ratio: default 120 (Solis provide AKH-0.66-K-80*40-600a), if the user install their own CT, then they need to set the CT ratio manually. If the system has the Eastron Meter connected, then the CT ratio needs to be set to Meter.
- CT direction: When a CT is installed correctly, select “Forward”. If the CT is found to be installed backwards, select “Reversal” to correct it. Otherwise, if the CT is left backwards then the sampling current of the CT will be reversed when calculating the power.



6. Commissioning

(4)Grid code:

Select grid code that meet the local regulations.

Three level of Over-voltage / under-voltage / Over-frequency / under-frequency are default based on grid code, there is no need to set the parameters in manual.

Grid Port

Grid Code

EN50549NL

HV1

253.0V

--

1.20s

HV1_T

HV2

253.0V

--

1.20s

HV2_T

HV3

6553.5V

--

-0.01s

HV3_T

LV1

184.0V

--

1.20s

LV1_T

LV2

184.0V

--

1.20s

LV2_T

LV3

57.5V

HF1

51.00Hz

--

1.20s

HF1_T

HF2

51.00Hz

--

1.20s

HF2_T

LF1

48.00Hz

--

1.20s

LF1_T

LF2

48.00Hz

--

1.20s

LF2_T

Startup-VH

253.0V

>

Startup-VL

195.5V

>

Recover-VH

253.0V

>

Recover-VL

195.5V

>

Select Country/Region

General

User-define

Other

A

Aruba

Australia

Austria

B

Barbados

Belgium

Brazil

C

Chile

China

Cyprus

Czech


D

6. Commissioning

(5)Storage mode:

ALL modes first priority is to use the available PV power to support loads. The different modes determine what the second priority, or use of the excess PV power, will be.

Self-use / Selling first / Off-grid are exclusive the user could select only one mode.



Settings	Description
Self-use	PV power flow priority sequence: loads > battery > grid. In this mode, the system stores excess PV power into the battery after the loads are supplied. If the battery is charged full, or there is no battery, the excess PV power will be exported(sold)back to the grid. If the system is set to not export any power, then the inverter will curtail the PV power (derate the inverter output power).
Selling first	PV power flow priority sequence: loads > grid > battery. In this mode, the system exports any excess PV power after the loads are supplied. If the export power quota has been met, then the remaining PV power will be stored in the battery. Notice: This mode should not be used if export power set to zero.
Off grid	PV power flow priority sequence: loads > battery. This mode only used when the system are not electrically connected to the grid at all. This mode is like Self-Use Mode, but the PV power will be curtailed if the PV power output is > battery power + load power.

Table 5 Description of Storage modes

Once quick setting finished, tap “Complete”, the APP enter the homepage.

6. Commissioning

6.6.3 Home Page of the Mobile App Inverter Interface

This screen display energy production and consumption, as well as its flow. It shows the following data:

- Today yield of PV
- Today Imported/Exported of Grid
- Today Charged/Discharged of Battery
- Today Consumption of Grid-side load
- Today Consumption of Back-up load
- Today GEN yield.


At the bottom of page are four sub menus: Home, Info, Alarm and Settings.



6. Commissioning

6.6.4 Settings


Under this page, the user could find quick setting and other detailed settings as follows:




1. Storage mode

a. Select storage mode:

- Self-use / Selling first / Off-grid, these three modes are exclusive, the user could select only one mode. The modes definition could refer to 5.5.2"Quick setting"
- The Mode description please refer to 5.4.1.



6. Commissioning



Please notice:
“Allow export” can only be set in “Self use” mode;
“Add time slot” can only be set in grid-connected mode (Self use” mode and “ Selling first” mode).


b. Set mode operations:

Settings	Description
Battery reserved	Range: Over Discharge SOC-100%, default:80%, settable. When battery SOC < set battery reserve SOC, battery will stop discharging.
Allow export	When it enables, the system is allowed to export power to grid.
Max export power	Default: 1.1 times of rated power. Notice: If feed-in is not allowed, set Max export power to 0.
Export calibration	Range : -500w-500w, default 20w, settable. To compensate the deviation of CT/Meter in practical application.
Allow grid charging	Allow grid charging the battery when it enables. Notice: if “Allow Grid Charging” is turned on, the inverter will use grid power to charge the battery only under two circumstances: •The battery drains to the Force Charge SOC. •When PV power output can't meet the set current value during the charge periods.

Table 6 Set mode operations

6. Commissioning

c. Add time slot:



Charge SOC: battery charging stops when reach the set SOC;
Discharge SOC: battery discharging stops when reach the set SOC.




- NOTICE:**
- Slide the switch to on, the battery charge/discharge with set charge/ discharge current by following the set period
 - Slide to the left of screen, the user could delete the current period setting.

6. Commissioning

2. Battery setting

- a. Set “ Number of Battery Banks” and “Battery Model”
- b. Set “Battery Connection Method” : 1 Batt 1 DC / 1 Batt 2 DC / 2 Batt;
- c. Set battery parameters



Settings	Description
Max charge current	Max charge current, settable.
Max discharge current	Max discharge current, settable.
Over discharge	Range : 5~40%, default 20%, when battery SOC < over discharge, it will stop discharging.
Recovery	Range : set Over discharge value +1% ~ set Over discharge value +20%; when battery SOC Recovery SOC, it will start charging, reserve the return difference value to avoid the battery repeatedly cross jump between charging and discharging.
Force charge	Range : 4%~ set Over discharge value, when battery SOC < force charge SOC, the grid will charge the battery.

Table 7 Battery setting




NOTICE:

Force charge SOC < Over discharge SOC < Recovery SOC, otherwise the setting might be error.

6. Commissioning




d. If two battery banks share the same setting, then turn the “Apply Batt1 parameter values” on. It will match the settings of battery bank 1 automatically.



3. Smart port

Select smart port type

- When it is connected to Generator, select “Gunset input”;
- When it is connected to smart load like heat pump, select “Smart load output”
- When it is connected to Grid-tied inverter, select “AC coupled”



Genset Rated Power: manual input.

OFF: Generator stops charging SOC, settable, range:35~100%;

ON: Generator start charging SOC; settable, range:1~95%;

AC coupled:

OFF: Grid-tied inverter stops charging SOC, settable, range:35~100%;

ON: Grid-tied inverter start charging SOC; settable, range:1~95%;


6. Commissioning

4. Grid port

Please refer to “5.5.2 APP Quick setting”

5. Parallel setting

When there are ≥ 2 inverters in parallel, turn the slider on
Set primary and secondary machine,
Set primary ID as: 1
secondary machine ID as: 2
.secondary machine ID as: 3
..... and so on.



6. Basic setting


Set inverter time and date, tap the slider next to “Follow Phone Time”, then tap “Save”.

6. Commissioning

7. CT/Meter setting


There are two ways for CT/Meter setting, detailed setting please refer to “5.5.2 APP Quick setting”.

Method 1: Quick setting




6. Commissioning

Method 2: Setting --- Professional Setting -- Device Setting --Meter/CT Setting



6.6.5 Alarm



The alarm page can display the current alarm and the historical alarms.



6. Commissioning

6.6.6 Information

- The use could Query information of PV / Battery / GRID / LOAD / INVERTER.
- PV : it display each PV module Power/Voltage/Current, as well as historical yield information calculated by monthly / yearly / total, displayed with graphics;
- BATT: it display battery Power/Voltage/Current/SOC/SOH/Max.charging current / Max.discharging current, as well as historical battery charging and discharging information calculated by monthly / yearly / total, displayed with graphics;
- GRID: it display Active power / voltage/ current of L1/L2/L3, as well as historical exported/imported information calculated by monthly / yearly / total, displayed with graphics;
- LOAD: it displays power/voltage of grid load, power/voltage/current of backup load;
- INV: it displays inverter SN/model number, and software version.



6. Commissioning

INV_112233445566C7C8

PV

BATT

GRID

LOAD

INV

PAR

0kWh

Today Exported

0kWh

Today Imported

0kWh

Today Exported

0kWh

Today Imported

Historical Exported&Imported Info

Inverter

	L1	L2	L3
Active Power	0W	0W	0W
Voltage	0V	0V	0V
Current	0A	0A	0A
Total Power	0W		
Frequency	0.00Hz		

Meter

	L1	L2	L3
Active Power	0W	0W	0W
Voltage	0V	0V	0V

Home

Info

Alarm

Setting

INV_112233445566C7C8

PV

BATT

GRID

LOAD

INV

PAR

0kWh

Today Grid Load

0kWh

Today Backup Load

0kWh

Today Grid Load

0kWh

Today Backup Load

Grid Load

	L1	L2	L3
Power	0W	0W	0W
Voltage	0.0V	0.0V	0.0V

Backup Load

	L1	L2	L3
Power	0W	0W	0W
Voltage	0.0V	0.0V	0.0V
Current	0.0A	0.0A	0.0A

Home

Info

Alarm

Setting

INV_112233445566C7C8

PV

BATT

GRID

LOAD

INV

PAR

Inverter

SN

112233445566C7C8

Model

5305

Rated Power

50kW

DSP Version

V0000

ARM Version

V0378

HMI Version

V010F

AFCI Version

V0000

Inverter Time

2024-08-01 16:02:09

Genset

Today Yelid

0.0kWh

Total Yelid

0kWh

Power

0W

Frequency

0.00Hz

Home


Info

Alarm

Setting

6. Commissioning


6.6.7 APP interface structure



7.1 Storage mode description

Self-Use mode

Solis S6 Series inverter does not require any regular maintenance. However, cleaning the heatsink will help the inverter dissipate heat and increase the lifetime of inverter. The dirt on the inverter can be cleaned with a soft brush.



How to set Self-Use mode?

APP: setting--storage mode-self use

1. Self-Use Mode is activated without any specific times set for the battery to be charged/discharged, and the battery reserve is not switched on.

Note: Solis recommends activating the 'Allow Grid Charge' option. Once the battery reaches the Forcecharge SOC, it will use the grid to charge the battery, preventing it from being deep discharged.

2. The Self-Use Mode provides you with the option to set a Battery reserve value. Please toggle the switch to activate the battery reserve mode.

3. The Self-Use Mode provides you with the option to set whether allow power output to the grid and the max value.

4. If there is an error with your meter or CTs, open "Export power calibration" to calibration; In addition, you can set a small negative value(like:-50W)to ensure that no power is sent to the grid to achieve Zero export Power.

5. When your load is unbalanced in the three-phase distribution, turn on unbalanced output.

6. You can set the value of Grid peak shaving, Limit the power that inverters can obtain from the grid to prevent exceeding regulatory requirements or the power line capacity due to excessive power.

7. With the Add time slot, you can customize 6 stages of charging and 6 stages of discharging in one day.

7. Feature Introduction

Under each mode , user could set other functions based on their requirements.

Settings	Description
Batt saving	Lithium battery: default 80%, adjustable range This function recommended to be enabled in weak grid area or where grid outages occur frequently. When enabled: battery SOC < set battery reserve SOC, battery will stop discharging and charged from PV/Grid.
Allow export	Allow power output to the grid in Self-use mode. If you do not want to send power to the grid, do not turn it on discharging and charged from PV/Grid.
Max export power	Limit the maximum power sold to the grid.
Export power calibration	To compensate the deviation of CT/Meter in practical application; Value : Settable. Please note : The parallel system should be set at 0.5% of the total capacity of the parallel system; otherwise, the anti-reverse flow performance requirements cannot be met.
Unbalanced output	Allow three-phase output imbalance.
Grid peak shaving	Limit the power that inverters can obtain from the grid to prevent exceeding regulatory requirements or the power line capacity due to excessive power. When the grid supplies power to the load while charging the battery, it will limit the power used to charge the battery, so that the total power does not exceed the set value. If the grid only supplies power to the load and does not charging the battery, it is not limited by the setting value.
Allow grid charging	Allow the battery to be charged by the grid.
Charge/ Discharge Slot	When the time is between Start and Stop, the system will charge/ discharge the battery according to the set Current until the set "SOC/voltage" is reached.

Selling first mode


Load priority: load>grid>battery

Power supply priority: PV>battery>grid>DG

This mode applies to the area that has high feed-in tariff and export control. The PV power will prioritize supplying energy to the load. Then any surplus is directed into the grid.

If there is a feed-in limitation, the excess power will charge the battery.

- Supports TOU setting in this mode.
- Supports Battery Reserve function in this mode.



How to set selling first mode?


APP: setting--storage mode--selling first.

Off-Grid mode

Load priority: load>battery

Power supply priority: PV>battery>DG

- This mode applies to the area not covered by the grid or when the system is not connected to the grid.
- When a power outage is detected in a grid-tied system, the system will automatically enter in the off-grid, supplying only the backup load.
- The user can also manually set this mode, supplying only the backup load.



How to set Off-Grid mode?

APP: setting--storage mode--off-grid

When there is need for Off-grid use, make sure that the rated power of the Backup load is within the inverter backup rated output power range of the inverter. Otherwise, the inverter will report an Overload Fault alarm(Fault code: 1057). The inverter will automatically clear the fault when the 1057 overload faults occur. When it keeps alarming there for this fault, turn off some loads to meet the rated backup output power range of the inverter, and then restart the inverter for a response.

For inductive loads such as refrigerators, air conditioner, washing machine, etc., ensure that the start power in total does not exceed the Backup peak power of the inverter.

Type of load	Equipment	Start power
Resistive load	Lamp	Rated power
	Fan	
	Hair dryer	
Inductive load	Refrigerator	3-5 times rated power
	Air conditioner	3-6 times rated power
	Washing machine	3-5 times rated power
	Microwave oven	3-5 times rated power

Peak shaving mode

Step1:

Setting--Grid peak shaving(turn on and set the limit value)

Step2:

Setting--Professional(password: 0010)--Function Setting--peak shaving.


In this mode, Power supply priority:

PV>grid>battery>DG(when BAT SOC≤baseline SOC);

PV>battery>grid>DG(when BAT SOC≥baseline SOC);

on the premise that the power supplied by the grid does not exceed the set value(P_max), the system will be trying to charge the battery to Peak SOC.

If($P_{\text{discharge}} + P_{\text{max}} + PV < P_{\text{load}}$), it will exceed the set value(P_{max})to support the load.



Settings	Description
Max export power	Default: 1.1 times of rated power. Notice: if feed-in is not allowed, set Max export power to 0.
Export calibration	To compensate the deviation of CT/ Meter in practical application . The parallel system should be set at 0.5% of the total capacity of the parallel system; otherwise, the anti-reverse flow performance requirements cannot be met.
Grid peak shaving	Default enable, default 2 times of rated power. Limit the power drawn from the grid to prevent from exceeding regulatory requirements or the power line capacity.

7.2 Time Of Use

Set “Time of use” under each mode (Skip this step if no need)

Time of Use is for manual control of the battery charging/discharging. It is for customizing when the battery is allowed to charge and discharge power and at what rate , established by a current (amperage)setting.

This function has prior logic to other storage modes.

- 1 . Charge period: battery charges with set current value until the charging cut-off voltage (settable), checking the box to control whether enable this charging period.
- 2 . Discharge period: battery discharges with set current value until the discharging cut-off voltage (settable) , checking the box to control whether enable this discharging period.

STORAGE MODE

2024/01/01 12:00:00

Charge period

	Start	Stop	Current	SOC
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%

Discharge period

	Start	Stop	Current	SOC
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%
☒	01 : 00 - 05 : 00		100A	50%
☐	01 : 00 - 05 : 00		100A	50%

2/2


7.3 AC coupling system

Generally, the access of grid-tied inverter is for the retrofit of a existing PV plant.

The S6 hybrid inverter support access of both Solis grid-tied inverter and third-party grid-tied inverter.

And S6 hybrid support two ways of connection of grid-tied inverter (Smart port and grid side)

1. Access of grid-tied inverter(Smart port)



(1)Requirements of grid-tied inverter


- Rated power of grid-tied inverter $\leq$ Hybrid rated power;
- Only support three phase grid-tied inverter. Single phase grid-tied inverter not supported;

(2)Control logic

- On-grid scenario: Hybrid and grid-tied inverter are grid follower, hybrid cannot control the output power of the grid-tied inverter, it controls the smart port relay between hybrid and grid-tied inverter to achieve 0 export(When battery SOC > fixed SOC, hybrid will turn off the smart port relay to stop the output of grid-tied inverter).
- Off-grid scenario: Hybrid acts as grid former and control the output of the grid-tied inverter by adjusting the frequency, the third-party grid-tied inverter must be configured with the correct grid code and equipped with over-frequency load shedding and under-frequency load rising functionalities.

(3)Setting path


【Smart port-----AC coupled----Max export control----Based on export power&SOC】




Access of third-party grid-tied inverter(Grid side)

Working with grid-tied inverter and monitor the grid-tied inverter output via meter. The output power of the grid-tied inverter can be displayed on soliscloud use the same meters in parallel.

Meter1 address: 001 (grid side), meter2 address: 002 (PV inverter).



For specific dual-meter wiring, please refer to the diagram below.



Procedure:

Step 1: Select the Professional Setting

Step 2: Select the Device Setting

Step 3: Select the Meter/CT Setting---- Meter


Select the Meter Type---- Meter

Select the Meter/CT Installation Location----Grid +PV Inverter



NOTE:

If there is need for the hybrid inverter to control the whole AC-Coupled system to reach zero export, Solis Grid-tied inverter must be used for communication.



7.4 Generator integrated system

1. The backup PE must be directly connected to the PE copper bar of the power distribution box, rather than the inverter shell.
2. The generator itself needs to be grounded, connected to the electric box, and connected to the inverter generator port.
3. When the generator is working, disconnect the Grid breaker or leakage current protector on the side of the power box immediately.



NOTE:

If you want use the smart port to connect a generator, there is no limit to the generator capacity. However, the maximum active power that the smart port can obtain from the generator is 125 kW. We recommend that the generator power should be in the range: 25 kW~ 125 kW.




NOTE:


If you need connect the generator on inverter smart port or inverter grid port , when you are connecting the power cable, you should keep the cable conned in right correspond phase sequence.
For example: if you do the wrong operation , like connecting the A phase point form Inverter to the B or C phase point from generator, when you want start generator, the inverter will report alarm and the generator cannot start normally!

7.4.1 Diesel Generator Wiring

1. The backup PE must be directly connected to the PE copper bar of the power distribution box, rather than the inverter shell.
2. The generator itself needs to be grounded, connected to the electric box, and connected to the inverter generator port.
3. When the generator is working, disconnect the Grid breaker or leakage current protector on the side of the power box immediately.

7. Feature Introduction









Generator setting

APP: setting--Smart Port

- A. Select Genset input when genset connect to the grid side, enable genset connected to grid.
- B. Set the Genset rated power.
- C. When you want to manually control the start and stop of the generator, enable needs to be selected.
- D. When you want the generator to automatically start and stop according to the battery SOC, please select the Automatic.

The generator will start when the battery SOC drops to the ON SOC, and stop when the SOC reaches the OFF value.



Generator communication connection(GEN-DO1/GEN-DO2/GEN-DI1/GEN-DI2)

The GEN-DO1(Pin11 , Pin12) , GEN-DO2(Pin13 , Pin14) are DO ports. You can use this ports to output dry contact signal to generator to control the generator start or stop automatically.

Both GEN-DO1 & GEN-DO2 are normally open and only close when generator startup logic is triggered.

The GEN-DI1 (Pin5 , Pin6), GEN-DI2 (Pin7 , Pin8) are DI ports , these two ports can be used when you connect the generator on the grid side with an ATS.

The GEN-DI1(Pin5, Pin6) on the inverter is dedicated to connect to the ATS on the dry contact point, when the grid is down, the ATS will close/connect the circuit of the dry contact, then the inverter can identify and enter generator operation mode, when the grid comes back, the dry contact will be open/disconnected and vice versa for the inverter.

The GEN-DI2(Pin7, Pin8) on the inverter is dedicated to connect to a power adapter(220V.ac~to 5/12V.dc) on the grid side. This power adapter will follow the available/unavailable status with the grid by providing 5/12V or 0V to the inverter so that the inverter knows when the grid is down or comes back and acts accordingly.

7.5 Parallel system

1.Before doing the parallel mode, please upgrade all the inverter to the latest version(ARM&DSP).

2.Check if the inverters are the same model. Eg, match a 125kW inverter with 125kW inverter.

Do not install inverters in parallel mode from different model!

3.When there are up to 6pcs of inverters working in parallel mode, the on-grid to off-grid switching time is less than 20ms. When there are up to 7~10pcs of inverters working in parallel mode, external switching devices such as STS must be installed to prevent damage to the inverters' relays.

4.It is recommended that the specification and total capacity of battery on the primary and secondary inverter be same; If it's different, connect the battery of larger capacity to the primary inverter, if the battery with larger capacity is connected to a secondary inverter , may fail to fully discharge in heavy load scenarios.


5.Parallel connection of Battery port is not supported between each inverter, each inverter should have its own battery connected independently.

6.When the current on each phase of the grid side is over 300A, for which indicates sum of the load and the inverter system output capacity, customers need to equip their own CT, which can meet the secondary side current of 5A.

7.Max. total parallel distance: <60m

We recommend that the backup load of the parallel system be configured at 90% of the system's rated power.

7. Feature Introduction





Up to 6 units of the inverter can be connected in parallel, if you have demand for 7-10 pcs in parallel mode, you should ask local solis technology support.

Please connect the paralleled inverters by using P-A and P-B terminals.

Standard CAT5 with shielding layers internet cable can be used.

1. ALL inverter MUST be connected to their own HV battery.
2. NOT support two or more inverters connect to the same one battery.



NOTE:

The primary is set with an ID of 1, secondary1 should have an ID of 2, secondary2 should have an ID of 3, and so on.


In a parallel system, if the battery number configuration is not one-to-one sufficient, only the secondary machine can be left unconnected, while the primary machine must be connected to the battery.

And the battery which one has the highest capacity we recommend you connect it to primary machine is better for system stability.



NOTE:

If the parallel machine is connected to the first and last consoles of the parallel connection, you need to put the DIP switch on the ARM board to "ON" position, and all the middle machines' DIP switch should be put to "OFF" position.






Procedure:

Step 1.Select Parallel setting

Step 2.Set the primary ID to 1

Step 3. Set the Salver ID to 2,3,4 and so on....



NOTE:

When under parallel system(inverter amount > 2), the AC cable length difference from inverter grid/backup port to the busbar should not exceed 10%.



NOTE:

If the inverter amount ≥ 2 in parallel mode on site , you must set the parallel mode on Solis app for each inverter in case of avoiding the damage to inverter when power on, the specific setting method can refer to the chapter.



NOTE:

Except the battery settings, all the operation parameters can be synchronized by the primary inverter to all the secondary inverters. The battery settings need to be set up separately because each inverter might have different battery conditions.

8. Troubleshooting

Solis US Technical Support Contact Information

Phone Number: +1(866)438-8408

Email: usservice@solisinverters.com

If you are having an issue with your system, please contact Solis Technical Support for assistance. If the inverter is having an issue, it will show it in one of the following ways: (1) the Inverter (circle) LED indicator light will flash orange. (2) the inverter status will be an alarm code (3) an alarm code will display on SolisCloud or (4) the inverter will simply be off. The next several pages explain how to troubleshoot each alarm code. If it is suspected that the issue is coming from the DC side of the system, it is recommended to turn the inverter off so that the PV strings can be more safely tested.

8.1 Inverter Maintenance

Solis S6 hybrid inverter does not require any regular maintenance. However, keeping the heatsink clean will ensure the inverter is able to dissipate heat, increasing the life span of the inverter. Any grease smudges on the inverter chassis can be cleaned off with soap and water.



CAUTION:

Do not touch the surface of the inverter it is operating. Some parts may be hot and could cause a minor burn. Turn off the inverter (refer to Section 6.2) and let it cool down before you do any maintenance or cleaning of it.

The LED status indicator lights can be cleaned with damp cloth if they are too dirty to be read.



Note:

Never use any solvents, abrasives, or corrosive materials to clean the inverter.

The inverter has been designed in accordance with international standards for safety and electromagnetic compatibility requirements. Before being shipped from the manufacturing center, the inverter is subjected to multiple tests to ensure operation reliability.

If you are not able to resolve the alarm code using the troubleshooting steps, or if the alarm code you are seeing is not listed, please contact Solis US Technical support. Use the Bluetooth tool, go to the Info page and then to the Inverter tab. Scroll down and tap Alarm History and then screen shot or write down the alarms as well as the dates and times the alarms were recorded. Please also take note of the inverter model number, serial number, and internal transmitter type.



NOTE:

If the inverter displays any alarm messages listed on the next few pages, please turn off the inverter and wait for 5 minutes before restarting it. If the alarm persists, please contact Solis after-sales service +1(866)438-8408 or email usservice@solisinverters.com

8. Troubleshooting

8.2 Inverter Alarm Codes

Message Name	Information Description	Troubleshooting Suggestion
Off	Control device to shutdown	1. Turn on the device in the ON/OFF Setting.
LmtByEPM	The device's output is under controlled	1. Confirm whether the inverter is connected to an external EPM/meter to prevent reverse current. 2. Confirm whether the inverter is controlled by an external third-party device. 3. Confirm whether the power setting of the inverter power control is limited. 4. Verify settings in section 6.6.7 and check your meter readings.
LmtByDRM	DRM Function ON	1. No need to deal with it.
LmtByTemp	Over temperature power limited	1. No need to deal with it, the device is in normal operation.
LmtByFreq	Frequency power limited	
LmtByVg	The device is in the Volt-Watt mode	1. Due to the requirements of local safety regulations, when the grid voltage is high, the Volt-watt working mode is triggered, which generally does not need to be dealt with. 2. Inverter factory test errors causing this mode to open, if you need to close, you can close this mode in LCD, set the process: Main menu → Advanced Settings → Password 0010 → STD mode settings → Working Mode → Working mode: NULL → Save and exit.
LmtByVar	The device is in the Volt-Var mode of operation	1. Due to the requirements of local safety regulations, when the grid voltage is high, the Volt-watt working mode is triggered, which generally does not need to be dealt with. 2. Inverter factory test errors causing this mode to open, if you need to close, you can close this mode in LCD, set the process: Main menu → Advanced Settings → Password 0010 → STD mode settings → Working Mode → Working mode: NULL → Save and exit.
LmtByUnFr	Under frequency limit	1. No need to deal with it.
Standby	Bypass run	
StandbySynoch	Off grid status to On grid status	
GridToLoad	Grid to load	

8. Troubleshooting

Message Name	Information Description	Troubleshooting Suggestion
Surge Alarm	On-site grid surge	1. Grid side fault, restart the device. If it is still not eliminated, please contact the manufacturer's customer service.
OV-G-V01	Grid voltage exceeds the upper voltage range	1. Confirm whether the power grid is abnormal. 2. Confirm that the AC cable is properly connected. 3. Restart the system and check if the fault persists.
UN-G-V01	Grid voltage exceeds the lower voltage range	
OV-G-F01	Grid frequency exceeds the upper frequency range	
UN-G-F01	Grid frequency exceeds the lower frequency range	
G-PHASE	Unbalanced grid voltage	
G-F-GLU	Grid voltage frequency fluctuation	
NO-Grid	No grid	
OV-G-V02	Grid transient overvoltage	
OV-G-V03	Grid transient overvoltage	1. Restart the system, confirm if that the fault continues.
IGFOL-F	Grid current tracking failure	1. Confirm whether the power grid is abnormal. 2. Confirm that the AC cable is properly connected. 3. Restart the system and check if the fault persists.
OV-G-V05	Grid voltage RMS instantaneous overvoltage fault	
OV-G-V04	Grid voltage exceeds the upper voltage range	
UN-G-V02	Grid voltage exceeds the lower voltage range	
OV-G-F02	Grid frequency exceeds the upper frequency range	
UN-G-F02	Grid frequency exceeds the lower frequency range	
NO-Battery	Battery is not connected	1. Check on information page 1 – Verify the battery voltage is within standards. 2. Measure battery voltage at plug.
OV-Vbackup	Inverting overvoltage	1. Check whether the backup port wiring is normal 2. Restart the system, confirm that the fault continues.
Over-Load	Load overload fault	1. Backup load power is too large, or some inductive load startup power is too large, need to remove some backup load, or remove the inductive load on the backup.

8. Troubleshooting

Message Name	Information Description	Troubleshooting Suggestion
BatName-FAIL	Wrong battery brand selection	1. Confirm whether the battery model selection is consistent with the actual one.
CAN Fail	CAN Fail	1. Can failure is a failure of communication between inverter and battery. Check cable conditions. Check to ensure you have it plugged in on the CAN port of the battery and inverter. Check that you are using the right cable. Some batteries require a special battery from the battery manufacturer.
OV-Vbatt	Battery overvoltage detected	1. Verify battery voltage is within standards. Measure battery voltage at inverter connection point. Contact your battery manufacturer for further service.
UN-Vbatt	Battery undervoltage detected	1. Restart the system and check if the fault persists. If it is still not eliminated, please contact the manufacturer's customer service.
Fan Alarm	Fan alarm	1. Check if the internal fan is working correctly or jammed.
OV-DC01 (1020 DATA:0001)	DC 1 input overvoltage	1. Check if the PV voltage is abnormal 2. Restart the system, confirm that the fault continues
OV-DC02 (1020 DATA:0002)	DC 2 input overvoltage	
OV-BUS (1021 DATA:0000)	DC bus overvoltage	1. Restart the system, confirm that the fault continues.
UN-BUS01 (1023 DATA:0001)	DC bus undervoltage	
UNB-BUS (1022 DATA:0000)	DC bus unbalanced voltage	
UN-BUS02 (1023 DATA:0002)	Abnormal detection of DC bus voltage	
DC-INTF. (1027 DATA:0000)	DC hardware overcurrent (1, 2, 3, 4)	1. Check if the DC wires are connected correctly without loose connection.
OV-G-I (1018 DATA:0000)	A phase RMS value overcurrent	1. Confirm that the grid is abnormal. 2. Confirm that the AC cable connection is not abnormal. 3. Restart the system, confirm that the fault continues.
OV-DCA-I (1025 DATA:0000)	DC 1 average overcurrent	1. Restart the system, confirm that the fault continues.
OV-DCB-I (1026 DATA:0000)	DC 2 average overcurrent	
GRID-INTF. (1030 DATA:0000)	AC hardware overcurrent (abc phase)	
DCInj-FAULT (1037 DATA:0000)	The current DC component exceeds the limit	1. Confirm that the grid is abnormal. 2. Confirm that the AC cable connection is not abnormal. 3. Restart the system, confirm that the fault continues.

8. Troubleshooting

Message Name	Information Description	Troubleshooting Suggestion
IGBT-OV-I (1048 DATA:0000)	IGBT overcurrent	1. Restart the system, confirm that the fault continues.
OV-TEM (1032 DATA:0000)	Module over temperature	1. Check whether the surrounding environment of the inverter has poor heat dissipation. 2. Confirm whether the product installation meets the requirements.
RelayChk-FAIL (1035 DATA:0000)	Relay failure	1. Restart the system, confirm that the fault continues.
UN-TEM (103A DATA:0000)	Low temperature protection	1. Check the working environment temperature of the inverter. 2. Restart the system to confirm if the fault continues.
PV ISO-PRO01 (1033 DATA:0001)	PV negative ground fault	1. Check whether the PV strings have insulation problems. 2. Check whether the PV cable is damaged.
PV ISO-PRO02 (1033 DATA:0002)	PV positive ground fault	
12Power-FAULT (1038 DATA:0000)	12V undervoltage failure	1. Check current leakage to ground. Verify your grounding. Verify all wires are in good condition and not leaking current to ground.
ILeak-PRO01 (1034 DATA:0001)	Leakage current failure 01 (30mA)	
ILeak-PRO02 (1034 DATA:0002)	Leakage current failure 02 (60mA)	
ILeak-PRO03 (1034 DATA:0003)	Leakage current failure 03 (150mA)	
ILeak-PRO04 (1034 DATA:0004)	Leakage current failure 04	
ILeak_Check (1039 DATA:0000)	Leakage current sensor failure	
GRID-INTF02 (1046 DATA:0000)	Power grid disturbance 02	1. Confirm whether the grid is seriously distorted. 2. Check whether the AC cable is connected reliably.
OV-Vbatt-H/ OV-BUS-H (1051 DATA:0000)	Battery overvoltage hardware failure / VBUS	1. Check if the battery circuit breaker is tripping. 2. Check if the battery is damaged.
OV-ILLC (1052 DATA:0000)	LLC hardware overcurrent	1. Check whether the backup load is overloaded. 2. Restart the system, confirm that the fault continues.
INI-FAULT (1031 DATA:0000)	AD zero drift overlink	1. Restart the system, confirm that the fault continues.
DSP-B-FAULT (1036 DATA:0000)	The primary-secondary DSP communication is abnormal	
AFCI-Check (1040 DATA:0000)	AFCI self-test failure	
ARC- FAULT (1041 DATA:0000)	AFCI failure	1. Verify connections are tight within your PV system. Arc fault settings can be changed in advanced settings if further adjustment is necessary.

8. Troubleshooting



NOTE:
The reconnection method of after AFCI failure: Automatic reconnection the AFCI type of each inverter model as:
S6-EH3P150K10-NV-YD-H-US AFCI type: F-I-AFPE-1-1-20
S6-EH3P125K10-NV-YD-H-US AFCI type: F-I-AFPE-1-1-20
S6-EH3P100K10-NV-YD-H-US AFCI type: F-I-AFPE-1-1-20
S6-EH3P75K10-LV-YD-H-US AFCI type: F-I-AFPE-1-1-20
S6-EH3P60K10-LV-YD-H-US AFCI type: F-I-AFPE-1-1-20

8.3 Service Ticket Information

When contacting the Solis Support team, it will speed up the process to obtain the information listed below before making the call. The inverter details can be found on the silver specification label on the side of the inverter. The alarm history can be found by navigating the LCD screen or through the SolisCloud app. Please keep the inverter online so that the service team can look at it remotely.

Item	Supplemental Information
Inverter serial number (SN)	Serial number can be found on the spec label
Inverter Firmware Version	A six character number that can be found in the information section of the inverter interface page - requires Bluetooth connection
Alarm history	Codes found in the Inverter section of the interface
DC voltages	Use a multimeter to measure the voltages
Detailed description of the problem	Frequency of the occurrence and any other relevant details about the issue
Battery serial number and Firmware version	Consult the battery product manual to determine how to collect this information
Is the system reporting to SolisCloud?	Yes/No - if yes, what is the site ID?
Take pictures showing all the cable connections in the system (Videos preferred)	If this is possible, it will help us to troubleshoot

8. Troubleshooting

8.4 Inverter Firmware

Solis inverters have a few different types of firmware that should all be on the latest version. If one site has several inverters installed, they should all be on the same versions to prevent errors.

Solis Inverter Firmware Types:

DSP: Digital Signal Processor

HMI: Human-Machine-Interface

AFCI: Arc-Fault-Circuit Interruption

To check which version the inverter is currently on, first connect to the inverter with Bluetooth. Go to the Information tab and be sure that you are on the Inverter tab. Scroll to the bottom and look for the DSP and HMI versions. The AFCI and SolisHub current versions can only be upgraded remotely with the assistance of Solis Technical Support.

There are two methods of updating the inverter firmware: (1) remotely (2) locally with Bluetooth,

7.4.1 Remote Firmware Updating

The inverter firmware can be updated remotely but only if the inverter has a Solis data logger connected directly to it. The logger must also be connected to the internet. Once that has been done, please call or email Solis Technical Support to request the firmware be updated remotely.

Please note: Only Solis Technical Support can update inverters **remotely**. Installers can only update firmware locally through the Bluetooth connection using the SolisCloud app.

7.4.2 Local Firmware Updating Through Bluetooth

The recommended method for updating the inverter firmware is locally using the SolisCloud Bluetooth tool. The steps for this process can be found on pages 61-62 (Step 3 of Commissioning). It is highly advisable to upgrade the inverter firmware during the commissioning process before configuring the settings.



IMPORTANT:

If there are multiple inverters in parallel, please connect one data logger to each inverter to ensure that firmware can be updated remotely. secondary firmware cannot be updated through a logger connected to the primary.
All inverters in the same system must be on the same firmware version.

9. Datasheet



100-150K

SOLARATOR SERIES

Operates Seamlessly with Generator: Experience Uninterrupted Power, Even in Areas with Grid Instability

S6-EH3P(100-150)K10-NV-YD-H-US

Three Phase | High Voltage



12 Unique Advantages

- ★ Supports PV input up to 250kW, maximising solar utilisation
- ★ Supports a maximum string input current of 21A, ensuring compatibility with high-power PV modules
- ★ Compatible with 100-314Ah battery modules, reducing overall system costs
- ★ Supports fast battery charging with a maximum charging current of 200A
- ★ Two independent battery ports for flexible configurations and easy capacity expansion
- ★ Delivers 160% overload for 200ms in off-grid mode, ensuring stable startup of heavy loads
- ★ Offers flexible control for weak grid and genset-hybrid scenarios, reducing investment costs
- ★ SolisCloud: Smart remote control, AI optimisation, and instant troubleshooting - all in one platform
- ★ Integrates PV and storage for demand management and anti-reverse flow functions
- ★ Provides dynamic reactive power compensation to improve grid power factor and reduce reactive power charges
- ★ Utility bypass function allows direct grid supply to backup loads
- ★ Patented cooling technology ensures reliable operation even under high-temperature conditions

6 Leading Advantages

- Supports both DC and AC coupling, for flexible retrofits and system expansions
- Ensures reliable backup power across diverse scenarios through battery reserve management
- Extends supply time for critical loads with intelligent load prioritization
- Offers a versatile three-in-one interface for seamless integration of on-grid PV, wind power, and diesel generators
- Achieves on- and off-grid transitions in less than 10ms, ensuring an uninterrupted power supply
- Supports multi-unit parallel operation up to 1.5MW (external ATS recommended for systems over 6 units)

USA

t: +1 866 438 8408

w: solisinverters.com/us

e: ussales@solisinverters.com

usservice@solisinverters.com



9. Datasheet

Models	100K	125K	150K
Input DC (PV side)			
Recommended max. PV array size	200 kW	250 kW	250 kW
Max. input voltage		1000 V	
Rated voltage		600 V	
Start-up voltage		180 V	
MPPT voltage range		150 - 950 V	
Max. input current		10 × 42 A	
Max. current per DC input		42 A	
Max. short circuit current		10 × 65 A	
MPPT number / Max. input strings number		10 / 20	
Battery			
Battery type		Li-ion	
Battery voltage range		300 - 950 V	
Max. charge / discharge current		100 A × 2	
Number of battery port / Number of BMS port		2	
Max. charge / discharge current of each port		100 A	
Communication		CAN	
Output AC (Grid side)			
Rated output power	100 kW	125 kW	150 kW
Max. apparent output power	100 kVA	125 kVA	150 kVA
Rated grid voltage		3/(N)/PE, 277 V / 480 V	
Rated grid frequency		60 Hz	
Rated grid output current	120.3 A	150.4 A	180.4 A
Power factor		> 0.99 (0.8 leading - 0.8 lagging)	
THDi		< 3%	
Input AC (Grid side)			
Max. input power	200 kW	207.8 kW	207.8 kW
Input voltage range		384 - 552 V	
Max. input current		250 A	
Output AC (Back-up)			
Rated output power	100 kW	125 kW	150 kW
Max. apparent output power	1.6 times of rated power, 10 s; 2 times of rated power, 200 ms	1.6 times of rated power, 10 s; 1.8 times of rated power, 200 ms	1.4 times of rated power, 10 s; 1.6 times of rated power, 200 ms
Back-up switch time ^①		< 10 ms	
Rated output voltage		3/(N)/PE, 277 V / 480 V	
Rated frequency		60 Hz	
Rated output current	120.3 A	150.4 A	180.4 A
Max. AC passthrough current	120.3 A	150.4 A	180.4 A
THDv (@linear load)		< 3%	
Input AC (Generator side)			
Max. input power	100 kW	125 kW	150 kW
Rated input current	120.3 A	150.4 A	180.4 A
Rated input voltage		3/(N)/PE, 277 V / 480 V	
Rated input frequency		60 Hz	
Efficiency			
Max. efficiency		97.6%	
CEC efficiency		97.2%	
BAT charged by PV / AC max. efficiency		98.5% / 97.0%	
Battery discharged efficiency		97.0%	
Protection			
Surge protection		DC Type II / AC Type II	
Output over current protection		Yes	
Insulation resistance monitoring		Yes	
Residual current detection		Yes	
Integrated PV switch		Yes	
DC reverse-polarity protection		Yes	
Protection class / Over voltage category		I / DC II, AC III	
Integrated AFCI 2.0		Yes	
Anti-islanding protection		Yes	
Rapid shutdown NEC 2017		Integrated SunSpec-certified Transmitter	
Compatible RSD receivers		See MLRSD Compatibility Sheet	
General Data			
Max. power per phase (grid & back-up)		33% rated power	
Dimensions (W × H × D)		50.47 × 33.94 × 18.43 in (1282 × 862 × 468 mm)	
Weight		374.79 lbs (170 kg)	
Inverter topology		Non-isolated	
Self-consumption		< 45 W	
Operating temperature range		-13°F to 140°F (-25°C to 60°C)	
Relative humidity		0 - 100%	
Ingress protection		TYPE 4X (IP66)	
Cooling concept		Intelligent redundant fan-cooling	
Max. operation altitude		3000 m	
Compliance ^②		UL Std. No.1741-Third Edition, UL1741 Supplement B and California Rule21 Phase 1&2&3, UL 1699B & CSA C22.2 No.107.1-16&IEEE 1547-2018, IEEE 1547a-2020 and IEEE 1547.1-2020, UL 1998, FCCPart15ClassB, HECO Rule 14H, NEC 690.12-2025, Hawaiian Electric Co.SRD-V2.0.	
Features			
PV connection		MC4 connector	
Battery connection		Spring clamp terminals	
AC connection		Screw type terminal block	
Interface		7.0" LCD display & Bluetooth + APP	
Monitoring platform		SolisCloud (modbus map and API sharing available upon request)	
Communication interface		Standard: WIFI+LAN+Bluetooth, CAN-BMS×2, CAN-Parallel×2, LAN, RS485-Meter, RS485, DRW, DI×4, DO×4; Optional: 4G	

① From On-Grid Mode to Off-Grid Mode: For a single inverter system, switchover time <10ms. For a parallel system which consists of up to 6 inverters, switchover time <20ms. If customer wishes to connect more than 6 inverters in parallel, please contact Solis Technical Team.

② This column only shows the planned certification standards. Please confirm the specific time of obtaining the standards with the local team.

9. Datasheet



75K

SOLARATOR SERIES

Operates Seamlessly with Generator: Experience Uninterrupted Power, Even in Areas with Grid Instability

S6-EH3P75K10-LV-YD-H-US

Three Phase | High Voltage



12 Unique Advantages

- ★ Supports up to 2x rated PV input, maximizing solar energy utilization
- ★ Supports a maximum string input current of 21A, ensuring compatibility with high-power PV modules
- ★ Compatible with 100-314Ah battery modules, reducing overall system costs
- ★ Supports fast battery charging with a maximum charging current of 200A
- ★ Two independent battery ports for flexible configurations and easy capacity expansion
- ★ Delivers 200% overload for 200ms in off-grid mode, ensuring stable startup of heavy loads
- ★ Offers flexible control for weak grid and genset-hybrid scenarios, reducing investment costs
- ★ SolisCloud: Smart remote control, AI optimisation, and instant troubleshooting - all in one platform
- ★ Integrates PV and storage for demand management and anti-reverse flow functions
- ★ Provides dynamic reactive power compensation to improve grid power factor and reduce reactive power charges
- ★ Utility bypass function allows direct grid supply to backup loads
- ★ Patented cooling technology ensures reliable operation even under high-temperature conditions

6 Leading Advantages

- Supports both DC and AC coupling, for flexible retrofits and system expansions
- Ensures reliable backup power across diverse scenarios through battery reserve management
- Extends supply time for critical loads with intelligent load prioritization
- Offers a versatile three-in-one interface for seamless integration of on-grid PV, wind power, and diesel generators
- Achieves on- and off-grid transitions in less than 10ms, ensuring an uninterrupted power supply
- Supports multi-unit parallel operation up to 750kW (external ATS recommended for systems over 6 units)

USA

t: +1 866 438 8408
w: solisinverters.com/us

e: ussales@solisinverters.com
usservice@solisinverters.com



9. Datasheet

Models	75K
Input DC (PV side)	
Recommended max. PV array size	150 kW
Max. input voltage	1000 V
Rated voltage	600 V
Start-up voltage	180 V
MPPT voltage range	150 - 950 V
Max. input current	10 × 42 A
Max. current per DC input	42 A
Max. short circuit current	10 × 65 A
MPPT number / Max. input strings number	10 / 20
Battery	
Battery type	Li-ion
Battery voltage range	300 - 950 V
Max. charge / discharge current	100 A × 2
Number of battery port / Number of BMS port	2
Max. charge / discharge current of each port	100 A
Communication	CAN
Output AC (Grid side)	
Rated output power	70 kW / 75 kW
Max. apparent output power	70 kVA / 75 kVA
Rated grid voltage	3/(N)/PE, 120 V / 208 V, 139 V / 240 V
Rated grid frequency	60 Hz
Rated grid output current	194.3 A / 180.4 A
Power factor	> 0.99 (0.8 leading - 0.8 lagging)
THDi	< 3%
Input AC (Grid side)	
Max. input power	90 kW / 103.9 kW
Input voltage range	166 - 276 V
Max. input current	250 A
Output AC (Back-up)	
Rated output power	70 kW / 75 kW
Max. apparent output power	1.4 times of rated power, 10 s; 1.6 times of rated power, 200 ms
Back-up switch time ^①	< 10 ms
Rated output voltage	3/(N)/PE, 120 V / 208 V, 139 V / 240 V
Rated frequency	60 Hz
Rated output current	194.3 A / 180.4 A
Max. AC passthrough current	194.3 A / 180.4 A
THDv (@linear load)	< 3%
Input AC (Generator side)	
Max. input power	70 kW / 75 kW
Rated input current	194.3 A / 180.4 A
Rated input voltage	3/(N)/PE, 120 V / 208 V, 139 V / 240 V
Rated input frequency	60 Hz
Efficiency	
Max. efficiency	96.0%
CEC efficiency	95.2%
BAT charged by PV / AC max. efficiency	98.5% / 95.6%
Battery discharged efficiency	95.6%
Protection	
Surge protection	DC Type II / AC Type II
Output over current protection	Yes
Insulation resistance monitoring	Yes
Residual current detection	Yes
Integrated PV switch	Yes
DC reverse-polarity protection	Yes
Protection class / Over voltage category	I / DC II, AC III
Integrated AFCI 2.0	Yes
Anti-islanding protection	Yes
Rapid shutdown NEC 2017	Integrated SunSpec-certified Transmitter
Compatible RSD receivers	See MLRSD Compatibility Sheet
General Data	
Max. power per phase (grid & back-up)	33% rated power
Dimensions (W × H × D)	50.47 × 33.94 × 18.43 in (1282 × 862 × 468 mm)
Weight	374.79 lbs (170 kg)
Inverter topology	Non-isolated
Self-consumption	< 45 W
Operating temperature range	-13°F to 140°F (-25°C to 60°C)
Relative humidity	0 - 100%
Ingress protection	TYPE 4X (IP66)
Cooling concept	Intelligent redundant fan-cooling
Max. operation altitude	3000 m
Compliance ^②	UL Std. No.1741-Third Edition, UL1741 Supplement B and California Rule21 Phase 1&2&3, UL 1699B & CSA C22.2 No. 107.1-16&IEEE 1547-2018, IEEE 1547a-2020 and IEEE 1547.1-2020, UL 1998, FCCPart15ClassB, HECO Rule 14H, NEC 690.12-2025, Hawaiian Electric Co. SRD-V2.0.
Features	
PV connection	MC4 connector
Battery connection	Spring clamp terminals
AC connection	Screw type terminal block
Interface	7.0" LCD display & Bluetooth + APP
Monitoring platform	SolisCloud (modbus map and API sharing available upon request)
Communication interface	Standard: WIFI+LAN+Bluetooth, CAN-BMS×2, CAN-Parallel×2, LAN, RS485-Meter, RS485, DRM, Di×5, DO×4; Optional: 4G

① From On-Grid Mode to Off-Grid Mode: For a single inverter system, switchover time <10ms. For a parallel system which consists of up to 6 inverters, switchover time <20ms. If customer wishes to connect more than 6 inverters in parallel, please contact Solis Technical Team.

② This column only shows the planned certification standards. Please confirm the specific time of obtaining the standards with the local team.

10. Appendix

10.1 Default Setting for IEEE1547-2018 (UL-480V-18)

Parameter	Adjustment Range (p.u.)	Default (p.u.)	Description
OV-G-V01	$1.10 < V \leq 1.21$	1.10 p.u.	Set grid over-voltage protection 01 value
OV-G-V01-T	0.1-13 S	13 S	Grid over-voltage protection 01 trip time
OV-G-V02	$1.20 < V \leq 1.30$	1.20 p.u.	Set grid over-voltage protection 02 value
OV-G-V02-T	0.1-5 S	0.16 S	Grid over-voltage protection 02 trip time
UN-G-V01	$0.5 \leq V < 0.88$	0.88 p.u.	Set grid under-voltage protection 01 value
UN-G-V01-T	2.0-50 Sec.	21 S	Grid under-voltage protection 01 trip time
UN-G-V02	$0.45 \leq V < 0.70$	0.5 p.u.	Set grid under-voltage protection 02 value
UN-G-V02-T	0.16-21 S	2 S	Grid under-voltage protection 02 trip time
UN-G-V03	$0.050 < V < 0.5$	0.5 p.u.	Set grid under-voltage protection 03 value
UN-G-V03-T	0.16-21 S	2 S	Grid under-voltage protection 03 trip time
OV-G-F01	$60.5 < F < 66 \text{ Hz}$	61.2 Hz	Set grid over-frequency protection 01 value
OV-G-F01-T	180-1000 S	300 S	Set grid over-frequency protection 01 trip time
OV-G-F02	$61.2 < F < 66 \text{ Hz}$	62 Hz	Set grid over-frequency protection 02 value
OV-G-F02-T	0.16-1000 S	0.16 S	Set grid over-frequency protection 02 trip time
UN-G-F01	$50 < F < 59 \text{ Hz}$	58.5 Hz	Set grid under-frequency protection 01 value
UN-G-F01-T	180-1000 S	300 S	Set grid under-frequency protection 01 trip time
UN-G-F02	$50 < F < 58 \text{ Hz}$	56.5 Hz	Set grid under-frequency protection 02 value
UN-G-F02-T	0.16-1000 S	0.16 S	Set grid under-frequency protection 02 trip time
Reconnection Voltage	$0.88 \leq V \leq 0.95$ $1.05 \leq V \leq 1.06$	0.917 p.u. 1.05 p.u.	Set grid recovery voltage range after grid fault
Reconnection Frequency	$59 \leq F \leq 59.9$ $60.1 \leq F \leq 61$	59.5 Hz 60.1 Hz	Set grid recovery frequency range after grid fault
Reconnection Time after Fault	0-600 S	300 S	Set reconnection time after a fault is cleared
Ramp-up Slew Rate	0.10-100%	100% W/S	Set Ramp-up power slew rate during start-up
Reconnect Slew Rate	0.10-100%	0.33% W/S	Set Ramp-up power slew rate during reconnect

10. Appendix

Parameter	Adjustment Range (p.u.)	Default (p.u.)	Description
Volt Watt P3Tau	0.5-60 S	10 S	Set the time to ramp up to 90% of the new active power target in response to the change in voltage
Volt Var Q3Tau	1-90 S	5 S	Set the time to ramp up to 90% of the new reactive power target in response to the change in voltage
Dead Band-OF	60.017-61 Hz	60.036Hz	Set OV frequency start dead band for power derate
Droop-OF	2-5 %	5 %	Set OV frequency derate droop slope
Response Time	0.2-10 S	5 S	Set frequency derate response time
Dead Band-UF	59-59.983 Hz	59.964 Hz	Set UN frequency start dead band for power derate
Droop-UF	2-5 %	5 %	Set UN frequency derate droop slope
Droop Pmin	0-100 %	0 %	Set frequency droop P minimum
Volt-Watt	Enabled/ Disabled	Enabled	Set Volt - Watt function
V1	Hybrid: $0.40 \leq V \leq 1.00$ Grid-tied: $0.90 \leq V \leq 1.30$	Hybrid: 0.5 p.u. Grid-tied: p.u.	Set grid voltage V1 limit for Volt-Watt control
P1	0-100 % Pn	100% Pn	Set power P1 for Volt-Watt control
V2	Hybrid: $0.60 \leq V \leq 1.05$ Grid-tied: $1.00 \leq V \leq 1.35$	Hybrid: 0.7 p.u. Grid-tied: p.u.	Set grid voltage V2 limit for Volt-Watt control
P2	0-100 % Pn	100% Pn	Set power P2 for Volt-Watt control
V3	$1.05 \leq V \leq 1.09$	1.06 p.u.	Set grid voltage V3 limit for Volt-Watt control
P3	0-100 % Pn	100% Pn	Set power P3 for Volt-Watt control
V4	$1.06 \leq V \leq 1.10$	1.10 p.u.	Set grid voltage V4 limit for Volt-Watt control
P4	0-100 % Pn	20% Pn	Set power P4 for Volt-Watt control
Volt-Var	Enabled/ Disabled	Enable	Set Volt-Var function
V1	$0.77 \leq V \leq 1.03$	0.92 p.u.	Set grid voltage V1 limit for Volt-Var control
Q1	0-60% Sn	+44% Sn	Set reactive power Q1 for Volt-Var control
V2	$0.92 \leq V \leq 1.05$	0.98 p.u.	Set grid voltage V2 limit for Volt-Var control
Q2	-60-60% Sn	0% Sn	Set reactive power Q2 for Volt-Var control
V3	$0.95 \leq V \leq 1.08$	1.02 p.u.	Set grid voltage V3 limit for Volt-Var control
Q3	-60-60% Sn	0% Sn	Set reactive power Q3 for Volt-Var control
V4	$0.97 \leq V \leq 1.23$	1.08 p.u.	Set grid voltage V4 limit for Volt-Var control
Q4	-60-0% Sn	-44% Sn	Set reactive power Q4 for Volt-Var control
Fixed PF	-0.8 -+0.8	1	Set Fixed Power Factor limit
Reactive Power	-60 -60 %	0%	Set Reactive Power level

10. Appendix

10.2 Default Setting for California Rule 21 (R21P3-24A)

Parameter	Adjustment Range (pu)	Default (pu)	Description
OV-G-V01	$1.10 \leq V \leq 1.21$	$1.10V_n$	Set grid over-voltage protection 01 value
OV-G-V01-T	$0.1 \leq t \leq 13$ S	13 S	Grid over-voltage protection 01 trip time
OV-G-V02	$1.20 \leq V \leq 1.30$	$1.20V_n$	Set grid over-voltage protection 02 value
OV-G-V02-T	$0.1 \leq t \leq 5$ S	0.16 S	Grid over-voltage protection 02 trip time
UN-G-V01	$0.05 \leq V \leq 0.88$	$0.88V_n$	Set grid under-voltage protection 01 value
UN-G-V01-T	$2.0 \leq t \leq 50$ S	21 S	Grid under-voltage protection 01 trip time
UN-G-V02	$0.05 \leq V \leq 0.70$	$0.5V_n$	Set grid under-voltage protection 02 value
UN-G-V02-T	$0.16 \leq t \leq 21$ S	2 S	Grid under-voltage protection 02 trip time
UN-G-V03	$0.05 \leq V \leq 0.50$	$0.5V_n$	Set grid under-voltage protection 03 value
UN-G-V03-T	$0.16 \leq t \leq 21$ S	2 S	Grid under-voltage protection 03 trip time
OV-G-F01	$60.5 \leq f \leq 66$ Hz	61.2 Hz	Set grid over-frequency protection 01 value
OV-G-F01-T	$180 \leq t \leq 1000$ S	300 S	Set grid over-frequency protection 01 trip time
OV-G-F02	$61.2 \leq f \leq 66$ Hz	62 Hz	Set grid over-frequency protection 02 value
OV-G-F02-T	$0.16 \leq t \leq 1000$ S	0.16 S	Set grid over-frequency protection 02 trip time
UN-G-F01	$50 \leq f \leq 59$ Hz	58.5 Hz	Set grid under-frequency protection 01 value
UN-G-F01-T	$180 \leq t \leq 1000$ S	300 S	Set grid under-frequency protection 01 trip time
UN-G-F02	$50 \leq f \leq 58$ Hz	56.5 Hz	Set grid under-frequency protection 02 value
UN-G-F02-T	$0.16 \leq t \leq 1000$ S	0.16 S	Set grid under-frequency protection 02 trip time
Reconnection Voltage	$0.88 \leq V \leq 0.95$ $1.05 \leq V \leq 1.06$	$0.917V_n$ $1.05V_n$	Set grid recovery voltage range after grid fault
Reconnection Frequency	$59 \leq f \leq 59.9$ $60.1 \leq f \leq 61$	59.5Hz 60.1Hz	Set grid recovery frequency range after grid fault
Reconnection Time after Fault	$0 \leq t \leq 600$ S	300 S	Set reconnection time after a fault is cleared
Ramp-up Slew Rate	0.10-100%	100%Pn/S	Set Ramp-up power slew rate during start-up
Reconnect Slew Rate	0.10-100%	0.33%Pn/S	Set Ramp-up power slew rate during reconnect

10. Appendix

Parameter	Adjustment Range (pu)	Default (pu)	Description
Volt Watt P3Tau	$0.5 \leq \tau \leq 60$ S	10 S	Set the time to ramp up to 90% of the new active power target in response to the change in voltage
Volt Var Q3Tau	$1 \leq \tau \leq 90$ S	5 S	Set the time to ramp up to 90% of the new reactive power target in response to the change in voltage
Dead Band-OF	$60.017 \leq f \leq 61$ Hz	60.036Hz	Set OF frequency start dead band for power derate
Droop-OF	2-5 %	5 %	Set OF frequency derate droop slope
Response Time	$0.2 \leq \tau \leq 10$ S	5 S	Set frequency derate response time
Dead Band-UF	$59 \leq f \leq 59.983$ Hz	59.964 Hz	Set UF frequency start dead band for power derate
Droop-UF	2-5 %	5 %	Set UF frequency derate droop slope
Droop Pmin	0-100 %	0 %	Set frequency droop P minimum
Volt-Watt	Enabled/ Disabled	Enabled	Set Volt - Watt function
V1	Hybrid: $0.40 \leq V \leq 1.00$ Grid-tied: $0.90 \leq V \leq 1.30$	Hybrid: 1.00Vn Grid-tied: 1.00Vn	Set grid voltage V1 limit for Volt-Watt control
P1	0-100 % Pn	100% Pn	Set power P1 for Volt-Watt control
V2	Hybrid: $0.60 \leq V \leq 1.05$ Grid-tied: $1.00 \leq V \leq 1.35$	Hybrid: 1.00Vn Grid-tied: 1.00Vn	Set grid voltage V2 limit for Volt-Watt control
P2	0-100 % Pn	100% Pn	Set power P2 for Volt-Watt control
V3	$1.05 \leq V \leq 1.09$	1.06Vn	Set grid voltage V3 limit for Volt-Watt control
P3	0-100 % Pn	100% Pn	Set power P3 for Volt-Watt control
V4	$1.06 \leq V \leq 1.10$	1.10Vn	Set grid voltage V4 limit for Volt-Watt control
P4	0-100 % Pn	Hybrid: 0%Pn Grid-tied: 0%Pn	Set power P4 for Volt-Watt control
Volt-Var	Enabled/ Disabled	Enable	Set Volt-Var function
V1	$0.77 \leq V \leq 1.03$	0.92Vn	Set grid voltage V1 limit for Volt-Var control
Q1	0-60% Sn	+30% Sn	Set reactive power Q1 for Volt-Var control
V2	$0.92 \leq V \leq 1.05$	0.97Vn	Set grid voltage V2 limit for Volt-Var control
Q2	-60-60% Sn	0% Sn	Set reactive power Q2 for Volt-Var control
V3	$0.95 \leq V \leq 1.08$	1.03Vn	Set grid voltage V3 limit for Volt-Var control
Q3	-60-60% Sn	0% Sn	Set reactive power Q3 for Volt-Var control
V4	$0.97 \leq V \leq 1.23$	1.07Vn	Set grid voltage V4 limit for Volt-Var control
Q4	-60-0% Sn	-30% Sn	Set reactive power Q4 for Volt-Var control
Fixed PF	-0.8 -+0.8	1.0	Set Fixed Power Factor limit
Reactive Power	-60 -60 %	0%	Set Reactive Power level

10. Appendix

10.3 Frequently Asked Questions

Q1: Why I have "CAN Fail" Alarm on the inverter?

A: "CAN Fail" indicates the CAN communication between inverter and battery is lost. Please double check if your CAN cable is correctly connected and if your battery is power on.

Q2: Why I have "BATName-Fail" Alarm on the inverter ?

A: Please check in the "Battery Setting->Battery Model" setting and confirm you selected the correct battery option as the nameplate of your battery module.

Q3: Why I have "MET-SLT-Fail" Alarm on the inverter?

A: Please check in the "Meter Setting->Meter Type" setting and confirm you selected the correct meter option corresponding to your smart meter.

Q4: Why the power values on the screen are fluctuating very fast?

A: If your loads are changing drastically, the inverter will adjust its power accordingly. If you confirm the loads are stable while the inverter power is changing very fast, please double check your meter CT's direction and make sure the arrow is towards grid.

Q5: Why I have "OV-ILLC" Alarm on the inverter ?

A: OV-ILLC indicates there is an overcurrent issue on the internal LLC circuit. It could be transient status during extreme condition such as overload. If it happens constantly or too frequent and the extreme conditions have been excluded, please contact Solis service team.

Q6: Why I have "OV-BATT-H" Alarm on the inverter ?

A: OV-BATT-H indicates over voltage issue on the hardware of battery circuit. It could be caused by high battery voltage at full SOC, battery suddenly switching off, etc. If it happens constantly or too frequent and the extreme conditions have been excluded, please contact Solis service team.

Q7: Why I have "No-Battery" Alarm on the inverter?

A: Please double check if the battery power cables have been correctly connected and the battery breaker (on battery or external) has been turn on. If you don't want to connect the battery for now, please select the "No battery" option in "Battery Setting->Battery Model" to prevent the alarm to show up.

10. Appendix

10.4 FCC Instructions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



FCC WARNING:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

10. Appendix

10.5 Data Collection & Storage

In order to improve our products and provide you with higher quality services, this device has a built-in data logging module for collecting relevant information during operation (such as power generation data, fault data)

Commitment:

1. We will only collect, use and process your device information for the purpose of improving our products and services.
2. We will take all reasonable and feasible measures to ensure that no irrelevant information is collected and we will protect your device information.
3. We will not share, transfer or disclose the collected device information with any company, organization or individual.
4. When we stop operating products or services, we will stop collecting information from your devices.
information in a timely manner.
5. If you do not want to provide such information, you can notify our company to turn off this function, which will not affect your normal use of other functions of the product.

Solis USA

Tel: +1(866)438-8408

Email: usservice@solisinverters.com

Web: www.solisinverters.com/us

If you encounter any problems with the inverter, please take note of the inverter serial number and then contact us using the phone number or email listed above.



Compliant with CA Rule 21 & HECO Rule 14H
Certified to UL 1741 SB
Certified to UL Std. No. 1741-Third Edition
& CSA-C22.2 No.107.1-16